




S9/S7

SOUND PANORAMA
SON PANORAMIQUE
SONIDO PANORAMA
KLANGPANORAMA
ЗВУКОВАЯ ПАНОРАМА


OPERATING INSTRUCTIONS
GUIDE D'UTILISATION
INSTRUCCIONES DE FUNCIONAMIENTO
BEDIENUNGSANLEITUNG
РАБОЧАЯ ИНСТРУКЦИЯ

Safety Information


READ THIS BEFORE OPERATING YOUR UNIT



CE R&TTE Directive 1999/5/EC

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION
TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE FRONT OR BACK COVER.
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE
PERSONNEL.

 This symbol indicates the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

 This symbol indicates important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION

- Leave space around the unit for sufficient ventilation.
- Avoid installation in extremely hot or cold locations, or in an area that is exposed to direct sunlight or heating equipment.
- Keep the unit free from moisture, water, and dust.
- Do not let foreign objects in the unit.
- Keep the ventilation openings clear of items, such as newspapers, linens, or curtains.
- Keep open flame from candles or other sources away from the unit.
- Observe the local regulations regarding disposal of packaging materials, exhausted batteries and old equipment.
- Do not expose the unit to dripping or splashing, or place objects filled with liquids such as vases.
- Do not let insecticides, benzene, or thinner come in contact with the unit.
- Never disassemble or modify the unit in any way.

Notes on the AC power cord and the wall outlet

- The unit remains connected to AC power as long as it is plugged into the wall outlet, even if the unit has been turned off.
- To completely disconnect this product from AC power, disconnect the plug from the wall socket outlet.
- When setting up this product, make sure that the AC outlet you are using is easily accessible.
- Disconnect the plug from the wall outlet when not using the unit for long periods of time.

Table of Contents

2 SAFETY INFORMATION

4 GETTING STARTED

- 4 What's Included
- 5 Parts Description

8 INSTALLATION

- 8 Installing the System
- 9 Installing the Remote Control Battery

10 CONNECTIONS

- 10 Subwoofer Connection
- 10 Connecting to HDMI Components
- 12 Connecting to Audio Components
- 13 Connecting the FM Antenna (Only for S9)
- 13 Power Connection

14 OPERATION

- 14 Listening to Your System
- 16 Listening to USB (Only for S9)
- 18 Listening to FM Radio (Only for S9)
- 22 Listening to Music via Bluetooth (Only for S9)

23 SETTINGS

- 23 Setting the System

25 TROUBLESHOOTING

27 SPECIFICATIONS

28 TRADEMARKS AND LICENSES

29 INDEX

Getting Started

What's Included



Main unit




Remote control (1 ea)



Battery (1 ea)



HDMI cable (1 ea)



Power adapter (1 ea)




FM antenna (1 ea)
(Only for S9)



User manual (1 ea)


Parts Description

Front Panel



- | | |
|--|---|
| 1 Sherwood BRAND | 3 Display Panel
Displays the current status of the main unit. |
| 2 Power Button
Press to turn the main unit on or turn off to standby mode. | 4 Volume Controller
Adjusts the volume level. |
| Input Selector
Rotate to select an input source for playback. | 5 USB Port (Only for S9)
Connects a USB device. |


Rear Panel



- 1 HDMI OUT**
See page **10**.
- 2 HDMI IN 1/2/3**
See page **10**.
- 3 DC IN**
See page **13**.
- 4 Power Switch**
See page **13**.

- 5 FM TUNER (Only for S9)**
See page **13**.
- 6 SUBWOOFER PRE OUT 1/2**
See page **10**.
- 7 AUX IN R/L**
See page **12**.
- 8 OPTICAL IN**
See page **12**.

Remote Control



- 1 SETUP**
Enters or exits the system setup menu.
- 2 SURROUND**
Selects surround mode.
- 3 DISPLAY**
Displays the current status of the main unit.
- 4 MUTE**
Mutes or activates the sound.


- 5 ►► (USB)**
Starts or pauses playback.
SEARCH.M (FM TUNER)
Searches FM tuner stations.
- (USB)**
Stops playback.
MO/ST (FM TUNER)
Toggles between FM stereo and mono modes.
- ◀◀ / ►► (USB)**
Skips to the next or returns to the previous file or track.
- REPEAT (USB)**
Selects a repeat function.
- < RDS/ RDS > (FM TUNER)**
Tunes to the previous or next RDS station.
- RANDOM (USB)**
Selects random playback.
- 6 SLEEP**
Sets a certain period of time for the main unit to be turned off.
- 7 DIMMER**
Dims or brightens the display panel.
- 8 ▲ / ▼ / ◀ / ▶**
 - Selects a file, folder, or track for music files.
 - Selects a setting option or menu.
- TUNE +/ TUNE -**
Tunes to a desired FM station.
- PRESET -/PRESET +**
Selects a preset FM station.
- ENTER/MEMO**
 - Confirms the selection.
 - Stores a preset station.
- 9 VOLUME**
Adjusts the volume level.
- 10 INPUT SELECT**
Selects an input source for play back.
- 11 ⏻ ON/STANDBY**
Turns on the main unit or turn off to normal standby mode.

Installation

Installing the System

To Install on a shelf


You can install the main unit on a shelf. Place the main unit at a height close to ear-level in the listening area.



When installing the main unit, use a stable surface to avoid accidents or injury.

To Install on a Wall

You can install the main unit on the wall. Before installation, see "CONNECTIONS" on page 10 and complete the wiring connections.




Caution


- When the main unit is installed on a wall, its weight could cause the screws to come loose over time, or it may not be adequately supported by the wall, resulting in the unit falling. Make sure that the wall you intend to mount the unit on is strong enough to support it. Do not mount on plywood or soft surface walls. If you are uncertain of the wall quality, consult a professional for an advice.
- Sherwood is not responsible for any accidents or damage that result from improper installation, misuse or modification of the product, or from natural disasters.
- Mounting screws are not supplied. Use screws suitable for the wall material and that can support the weight of the unit. It is recommended to use 2 inch (50 mm) long screws.
- The main unit is magnetically shielded. However, depending on the installation location, color distortion may occur if the main unit is installed extremely close to the screen of the TV. If this happens, turn the main unit off, and turn it on after 15 minutes. If the problem persists, move the main unit further from the TV.

Installing the Remote Control Battery

- 1 Press inward to release the lock (1), and at the same time, slide the battery holder out of the remote control with your fingernail (2).



- 2 Place the "+" (top) side of the battery down into the battery holder.
- 3 Push the battery holder back into its original position.




! Caution

- If the battery is placed incorrectly, it can cause explosion.
- Use only one CR2025 (3 V) lithium battery.
- Remove the battery if the remote control is not used for a long period of time.
- Do not leave the product in a hot or humid place.
- Do not handle and store the battery with metallic tools.

Connections

Subwoofer Connection

You can enjoy deep bass sounds by connecting an active subwoofer.




Active Subwoofer

! Caution

- Do not place objects behind the subwoofer and block the ventilation ports.
- Signal reception by the subwoofer may be unstable if it is placed too close to the main unit. In this case, separate the subwoofer at least 1 m from the main unit.
- Signal reception by the subwoofer may be interrupted if an obstruction (metal door or concrete wall, aluminum covered insulation, etc.) is placed between it and the main unit. If this occurs, install the subwoofer in an uninterrupted line-of-sight orientation from the main unit.

Connecting to HDMI Components

With HDMI, you can easily enjoy high quality sounds and images. The main unit plays audio from HDMI compatible products while also passing on the video signal to a HDMI-connected TV.



Confirming the HDMI control functions

To use the HDMI control functions properly, it is recommended to confirm the HDMI control functions usable with each connected component by performing the following operations.

- 1** Turn on all the components connected with HDMI cables.
- 2** Turn the TV off to standby mode.
 - Confirm that all the components are turned off.
- 3** With all the components off, start playback of a device (connected with HDMI cable).
- 4** Confirm that all the components are turned on and the inputs of the main unit and TV are switched automatically.

About HDMI

HDMI (High Definition Multimedia Interface) supports both video and audio on a single digital connection for use with DVD players, DTV, set-top boxes, and other AV devices. HDMI was developed to provide the technologies of High Bandwidth Digital Content Protection (HDCP) as well as Digital Visual Interface (DVI) in one specification. HDCP is used to protect the digital content transmitted and received by DVI-compliant displays.

HDMI has the capability to support standard, enhanced, or high-definition video plus standard to multi-channel surround-sound audio. HDMI features include uncompressed digital video, a bandwidth of up to 2.2 gigabytes per second (with HDTV signals), one connector (instead of several cables and connectors), and communication between the AV source and AV devices such as DTVs.

This main unit is also compatible with the DeepColor and x.v.Color feature (x.v.Color is trademarks of Sony Corporation.).

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing, LLC.



Note


- Check the setup of the connected component if an image is poor or the sound does not come out of a component connected via the HDMI cable.
- Audio signals (sampling frequency, bit length, etc.) transmitted from an HDMI jack may be suppressed by the connected component.
- When the connected component is not compatible with copyright protection technology (HDCP), the image and the sound from the HDMI TV OUT jack may be distorted or may be not output. In this case, check the specification of the connected component.
- Regardless of which input is selected for the system, the video signal from the HDMI input jack (BD, DVD, SAT) that was last selected is output from the HDMI TV OUT jack.

Connecting to Audio Components

AUX Connection

You can connect your audio devices to the unit and enjoy multichannel surround sound capabilities.


- Ensure the left (L) and right (R) channels and the inputs and outputs are correctly connected.
- To listen to the sound of a connected audio device, select AUX as the input source.
- To listen to TV audio, select TV as the input source.



Optical Connection

You can connect components equipped with an optical out jack. On the main unit, you can enjoy more plentifully the sound of components, such as DVD players, Satellite receiver/Cable boxes, BD (Blu-ray Disc™) players or TVs.

* "Blu-ray Disc" is a trademark of Blu-ray Disc Association.




Caution

- TVs without an optical jack cannot be connected to the unit.

Connecting the FM Antenna (Only for S9)

You can listen to FM radio by connecting the FM antenna to the FM terminal on the main unit.


To strengthen the signal reception, extend the antenna to its full length.



Power Connection

Make sure to plug in after you have connected all your components to the main unit. Plug the supplied AC input cord into the AC inlet and then into the wall AC outlet.

Make sure to turn on the power switch after plugging in. Otherwise, you cannot turn on the main unit even after plugging in completely and pressing the power button on the front panel.



! Caution

- The supplied AC adapter is designed exclusively for use with this unit. Do not attempt to use it with any device for which was not expressly designed, since fires or shocks may occur.
- Handle the power cord by the plug part. Do not pull out the plug by tugging the cord, and never touch the power cord when your hands are wet, as this could cause a short circuit or electric shock.
- The system should be disconnected by removing the main plug from the wall socket when not in regular use for a long period of time.


Operation

Listening to Your System


Basic Operation

You can listen to audio by following the basic procedures below.


- 1 Turn on the connected component.
- 2 Turn on the main unit.
 - On the main unit, press **PUSH ON/STANDBY**.
 - On the remote control, press **ON/STANDBY**.



- 3 Select an input source you want to play back.
 - On the main unit, rotate **INPUT SELECT**.
 - On the remote control, press **INPUT SELECT </>**.
 - Each time the button is pressed, the display changes as follows.
S9
HDMI1 → HDMI2 → HDMI3 → TV → AUX → OPTICAL → FM STEREO → USB → BLUETOOTH
S7
HDMI1 → HDMI2 → HDMI3 → TV → AUX → OPTICAL





- 4 Start playback of the component you selected in step 1.
- 5 During playback, you can adjust the volume level.
 - On the main unit, rotate the volume controller.
 - On the remote control, press **VOLUME +/-**.



Muting the Sound

You can mute the sound temporarily by pressing **MUTE**.

- 1 Press **MUTE** to mute the sound.
- 2 Press **MUTE** or **VOLUME - / +** to turn on the sound.



Selecting Surround Mode

This system uses OPSODIS Technology, which generates spatial sound, without having to use walls to reflect the sound. This creates the illusion of three-dimensional acoustics and enables you to experience the film soundtrack and music with a power and intensity not previously achieved. However, the options available will depend on the type of source you're listening to. The following modes provide basic surround sound for stereo and multichannel sources.

- 1 Press **SURROUND** to select **STEREO**, **3D STEREO**, or **3D SURROUND**.



- **STEREO**
STEREO reproduces realistic sound through the front speakers (and possibly your subwoofer depending on your speaker settings). Dolby Digital and DTS multichannel sources are downmixed to stereo with the aid of digital sound processing.
- **3D STEREO**
3D STEREO produces more sound expansion through 2 channel audio system with the aid of Opsodis sound processing.
- **3D SURROUND**
3D SURROUND enriches the sound reproduction quality of an 2 or 5.1 audio input source with the aid of virtual 5.1 channel 3D effects from speakers that surround the listener.


If the source is Dolby Digital, DTS, or Dolby Surround encoded, the proper decoding format will automatically be selected and appear in the display.

With two channel sources, you can select from:

- **DOLBY Digital**
Dolby Digital is a multi-channel digital signal format developed by Dolby Laboratories. Discs bearing the Dolby Digital logo include the recording of up to 5.1 channels of digital signals. This will put you right in the middle of the action, just like being in a movie theater or concert hall.
- **DTS**
DTS Digital Surround (also called simply DTS) supports up to 5.1 discrete channels and uses less compression for high fidelity reproduction. Use it with DVDs and CDs bearing the DTS logo.

Displaying Operation Status

- 1 Press **DISPLAY**.
Each time the button is pressed, the display mode changes as follows:
 - **USB**
Playback file status → Repeat setting
→ Random setting → Playback file status
 - **BLUETOOTH**
Paired device name → Surround mode
→ Signal input → Volume level
→ Paired device name
 - **HDMI**
HDMI → Surround mode → Signal input
→ Volume level → HDMI



Listening to USB (Only for S9)

You can play audio files from a USB device. However, editing or copying the data file is not possible.



Note

- The USB jack does not support the connection of other USB devices except for a USB flash drive or a USB memory card reader.
- When the USB device does not fit into the USB jack, a USB extension cable is required.
- You can only play back the content from the connected USB device.
- Copy-protected contents are not playable.

Playback Operation

To Stop Playback

- 1 During playback, press **■**.



- 2 To resume playback, press **▶||**.



To Play Repeatedly

- 1 During playback, press **REPEAT**. Each time the button is pressed, repeat mode changes as follows:

- **Repeat One**
Repeats the currently playing music file.
- **Repeat Fol**
Repeats all music files in the folder.
- **Repeat All**
Repeats all music files.



To Pause Playback

- 1 During playback, press **▶||**.
 - Playback will stop at the point where the button is pressed.
 - To resume playback from this point, press the button again.



To Play Randomly

- 1 During playback, press **RANDOM**.
 - "Random On" is displayed on the display panel.
 - All music files in the folder are played in random order.



To Skip Forward or Backward

- 1 During playback, press **◀◀** or **▶▶**.
 - Each time the button is pressed, a track is skipped forward or backward.



- 2 To cancel random playback, press **RANDOM** again.
 - "Random Off" is displayed on the display panel.




Note

- You can only use the skip mode, repeat mode and random mode when playing music files stored on a USB memory device.

Listening to FM Radio (Only for S9)


Auto Tuning

- 1 Press **TUNE +** or **TUNE -** for more than 2 seconds.
 - The tuner keeps searching until a station with strong signal strength is found. The display shows the tuned frequency.
 - If the station found is not the desired one, simply repeat this operation.
 - Stations with weak signal strength are skipped during auto tuning.



Auto Presetting

- 1 Press and hold down **ENTER/MEMO** for more than 2 seconds.
 - "AUTO MEMORY" blinks and the receiver begins to preset stations with strong signal.
 - Up to 30 FM stations may be stored.
 - To stop auto presetting, press **ENTER/MEMO** again.




Note

- FM stations with weak signal strength cannot be stored to memory.


Manual Tuning

- 1 Press **TUNE +** or **TUNE -** repeatedly until the desired station is found.




Manual Presetting


- 1 Tune in to the desired station with auto or manual tuning.
- 2 Press **ENTER/MEMO**.
 - A preset number blinks.



- 3 Select a desired preset number (1~30) by pressing **TUNE +** or **TUNE -**.
 - A station has now been stored in the memory.
 - A stored station is erased from the memory by storing another station in its place.




- 4 Press **ENTER/MEMO** again to confirm your selection.
 - The station has now been stored in the memory.
 - A stored station is erased from the memory by storing another station in its place.



- 5 Repeat the above steps 1 - 4 to store another station.

Tuning in to Preset Stations

- 1 Select **FM TUNER** as the input source.
- 2 Select a desired preset number by pressing **PRESET -** or **PRESET +**.



RDS Tuning

RDS(Radio Data System) is a method for sending information signals together with transmitter signals. Your tuner is capable of translating these signals and displaying the information.

These codes contain the following information: Program Service name(PS), A list of Program Types(PHY), Traffic Announcement(TA), Radio Text(RT).




Note

- In some countries, RDS tuner function may not be available.


RDS search

Use this function to automatically search and receive stations offering RDS services.

- 1 In the FM mode, press **SEARCH.M** to select the RDS search mode.
 - Each time this button is pressed, search mode changes as follows:
RDS SEARCH → TP SEARCH → PTY SEARCH(PTY NAME) → OFF




- 2 While "RDS SEARCH" is displayed:
 - The tuner automatically searches for stations offering RDS services and displays the name of the station.
 - If no RDS station is found, "NO RDS" is displayed.
 - When "RDS SEARCH" is not displayed, repeat again from step 1.



TP search

Use this function to automatically search and receive stations broadcasting the traffic program.

- 1 In FM mode, select the TP search mode.
 - "TP SEARCH" is displayed.



- 2 While "TP SEARCH" is displayed:
 - The tuner automatically searches for stations broadcasting traffic programs.
 - "NO TP" is displayed if the signal is weak or there are no stations broadcasting traffic programs.
 - When "TP SEARCH" is not displayed, repeat again from step 1.



PTY search

Use this function to automatically search and receive stations broadcasting a desired program type.


1 In the FM mode, select the PTY search mode.

- "PTY SEARCH (PTY NAME)" is displayed.



2 While displaying "PTY SRCH", press < RDS or RDS > to select a desired program type.

- Each time these buttons are pressed, one of 29 different types of programs is selected.
(NEWS, AFFAIRS, INFO, SPORT, EDUCATE, DRAMA, CULTURE, SCIENCE, VARIED, POP M, ROCK M, EASY M, LIGHT M, CLASSICS, OTHER M, WEATHER, FINANCE, CHILDREN, SOCIAL, RELIGION, PHONE IN, TRAVEL, LEISURE, JAZZ, COUNTRY, NATION M, OLDIES, FOLK M, DOCUMENT)
- When "PTY SEARCH (PTY NAME)" is not displayed, repeat again from step 1.




3 While a desired program type is displayed:


- The tuner automatically seeks a station offering PTY services.
- If no station is found, "NO PROG" is displayed.

Displaying RDS information

1 Press **DISPLAY**.



- Each time this button is pressed, display mode changes as follows:



- **Program Service Name (PS)**
The name of the radio station.
- **Program Type (PTY)**
This indicates the kind of program currently being broadcast.
- **Radio Text (RT)**
Messages sent by the radio station. For example, a talk show radio station may provide a phone number as RT.
- If signals are too weak or no RDS service is available, "NO NAME", "NO PTY" or "NO TEXT" will be displayed.

Listening to Music via Bluetooth (Only for S9)

The main unit uses Bluetooth wireless technology to stream music from your portable devices.



- 1 Turn on the main unit.
- 2 Press **INPUT SELECT** repeatedly to select **BLUETOOTH**.




- 3 Press **▲** to display "PAIRING" on the display panel.



- 4 Press **ENTER/MEMO** to display the pin code(0000) on the display panel.



- 5 Press **ENTER/MEMO**. "PAIRING" blinks.



- 6 Search and pair the main unit with your portable device.
The name of the main unit is displayed as **"Sherwood S9"** on your portable device.

- 7 When the pairing is complete, the paired device name is displayed on the display panel.



Note


- Before you connect a Bluetooth device to the main unit, familiarize yourself with the Bluetooth capabilities of the device.
- Keep the main unit away from other electronic devices that may cause interference.

Settings

Setting the System

You can set additional sound settings.

- 1 Press **SETUP**.



- 2 Press **▲** or **▼** to select **1 SYSTEM SET** or **2 HDMI SET**.



- 3 Press **ENTER/MEMO** to confirm.




- 4 Press **▼** to select an option.



- 5 Press **ENTER/MEMO** to confirm the selected setting.



- 6 Press **▲** or **▼** to set a value.



- 7 Press **ENTER/MEMO** to confirm.
 - To return to the previous menu, press **◀**.
 - To exit the menu, press **SETUP** again.



S9/S7 3D Sound Soundbar

* Default settings are shown in bold below.

Setting	Option	Descriptions	
1 SYSTEM SET	STANDBY (Auto Standby)	6hr	Sets the standby time for the system.
		4hr	
		2hr	
		OFF	
	DRC (Dynamic Range Control)	OFF	Adjusts the level of dynamic range for movie soundtracks optimized for Dolby Digital, DTS, Dolby Digital Plus and Dolby TrueHD (You may need to use this feature when listening to surround sound at low volumes.).
ON			
DELAY	0ms ~ 200ms	Some monitors have a slight delay during video playback, so the soundtrack will be slightly out of sync with the picture. By adding a bit of delay, you can sync the sound to the video. The delay can be adjusted within the range of 0 ms - 200 ms.	
SW LEVEL	Off ~ -20 ~ 0dB	Adjusts the sound level of the subwoofer.	
2 HDMI SET	HDMI (HDMI Audio)	AMP	Specifies the routing of the HDMI audio signal from the system (amp) or through to a TV or flat screen TV. When THRU is selected, no sound is output from the system.
		THRU	
	CEC	OFF	Allows input selection of this receiver to be interlocked with the operation of the connected components. The CEC Control function may not work depending on the connected component and its settings.
ON			



Note

- When the CEC Control is set to "ON", you can also use the ARC (Audio Return Channel) function, enabling TV to send audio signals to this receiver via a HDMI cable. To use the ARC function, TVs that support the ARC function of the HDMI 1.4 standards are required.

Troubleshooting

If you experience any of the following difficulties while using the system, use this troubleshooting guide to help remedy the problem before requesting servicing. Should any problem persist, consult your nearest authorized dealer or authorized independent company.

If the unit does not operate normally due to external influence such as static electricity, disconnect the power plug from the outlet and insert again to return to normal operating conditions.

GENERAL

Problem	Remedy
The power does not turn on.	<ul style="list-style-type: none"> Disconnect the power plug from the outlet, and connect again.
The system suddenly turns off.	<ul style="list-style-type: none"> After about a minute (you won't be able to turn the unit on during this time), turn the system back on. If the message persists, call an authorized independent service company.
No sound is heard after a function is selected.	<ul style="list-style-type: none"> Make sure the component is connected correctly. (See "CONNECTIONS" on page 10.) Press MUTE to restore the sound.
Can't operate the remote control.	<ul style="list-style-type: none"> Replace the batteries. (See page 9.) Operate within 7 m, 30° of the remote sensor Remove any obstacles, or operate from another position. Avoid exposing the remote sensor on the front panel to direct light.
The display is dark or off.	<ul style="list-style-type: none"> Press DIMMER on the control repeatedly to return to the default setting.

CONNECTED COMPONENTS

Problem	Remedy
There is no sound from the selected component.	<ul style="list-style-type: none"> Check that the component is connected correctly to the audio input jacks of components. Check that the cords are fully inserted into the jacks on both the component and the main unit. Ensure that the component is selected correctly.
Sound is interrupted or there is noise.	<ul style="list-style-type: none"> Check the output audio formats support system.
No sound is heard or there is noise when software with DTS is played back.	<ul style="list-style-type: none"> Set the digital volume level of the system to full, or to the neutral position. Ensure the player's settings are correct and/or the DTS signal out is on. Refer to the instruction manual supplied with the DVD player.
During playback search, there is noise from a DTS compatible CD player.	<ul style="list-style-type: none"> This is not a malfunction, but be sure to turn the volume down to prevent the output of loud noise from the system.

HDMI

Symptom	Remedy
No picture or sound.	<ul style="list-style-type: none"> If the problem still persists when connecting your HDMI component directly to your monitor, consult the component or monitor manual or contact the manufacturer for support.
No picture.	<ul style="list-style-type: none"> Depending on the output settings of the source component, the video format may not be displayed. Change the output settings of the source, or connect your source component directly to TV using the component or composite video jacks. This system is HDCP-compatible. Check that the components you are connecting are also HDCP-compatible. If they are not, please connect your source component directly to TV using the component or composite video jacks. Some source components will not work with this system (even if it is HDCP-compatible). In this case, connect your source component directly to TV using the component or composite video jacks. If video images do not appear on your TV or flat screen TV, try adjusting the resolution, DeepColor or other setting for your component. To output signals in DeepColor, use an HDMI cable (High Speed HDMI™ Cable) to connect this system to a component or TV with the DeepColor feature.
No sound, or sound suddenly ceases.	<ul style="list-style-type: none"> If you've made separate connections for audio, make sure you have assigned the analog/digital jack(s) to the corresponding HDMI input for the component. Check the audio output settings of the source component. If the component is a DVI device, use a separate connection for the audio.

Important Information Regarding the HDMI Connection

Some HDMI signals cannot be routed through this system. (This depends on the HDMI-equipped component you are connecting. Check with the manufacturer for HDMI compatibility information.)

If you cannot receive HDMI signals properly through this system (from your component), please try the following configuration when connecting up.

Specifications

Amplifier	
Rated power output Front Tweeter High/Low Front Woofer	25 W per channel (6 Ω , 1 %)
Input/Output	
HDMI terminal Input Output Audio input	HDMI INPUT x 3 HDMI OUTPUT 1 (ARC) AUX (Analog), Optical x1 (Digital)
Speaker	
Woofer Type Impedance	5" Cone Type 6 Ω
Tweeter Low Type Impedance	1" Dome Type 6 Ω
Tweeter High Type Impedance	0.8" Dome Type 6 Ω
General	
Power Requirements Power Consumption In standby Dimensions Weight (without package)	AC 100-240 V, 50/60 Hz (DC 24 V) AC 45 W (DC 1.8 A) 0.5 W or less 1,055 mm (W) x 145 mm (H) x 130.5 mm (D) 6.4kg (S9) / 6.3kg (S7)

Trademarks and Licenses

This system incorporates a sophisticated Digital Signal Processor that allows you to create optimum sound quality and sound atmosphere in your personal Home Theater.

DTS Digital Surround



DTS Digital Surround (also called simply DTS) supports up to 5.1 discrete channels and uses less compression for high fidelity reproduction. Use it with DVDs and CDs bearing the DTS logo.

Manufactured under license under U.S. Patent Nos: 5,956,674; 5,974,380; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS, the Symbol, & DTS and the Symbol together are registered trademarks & DTS Digital Surround and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.

Dolby Digital



Dolby Digital is the multi-channel digital signal format developed by Dolby Laboratories. Discs bearing the Dolby Digital logo include the recording of up to 5.1 channels of digital signals. This will put you right in the middle of the action, just like being in a movie theater or concert hall.

Dolby and the double-D symbol are trademarks of Dolby Laboratories.

HDMI



HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

OPSODIS



OPSODIS is a registered trademark of the OPSODIS LTD.

Opsodis and Opsodis Device are Trade Marks of Adaptive Audio Limited and are used under licence by Inkel corporation. Patents covering Opsodis technology are owned by Adaptive Audio Ltd and are also used under licence by Inkel corporation.

Bluetooth



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Inkel Corporation is under license. Other trademarks and trade names are those of their respective owners.

Index

A

About HDMI 11
Auto Presetting 18
AUX Connection 12

B

Basic Operation 14
Bluetooth 22

C

Connecting to HDMI Components 10

D

Displaying the Operation Status 16
DOLBY Digital 15
DTS 15

F

FM Antenna 13
FM Radio 18
Front Panel 5

I

Installing the Remote Control Battery 9
Installing the System 8

L

Listening to USB 16

M

Manual Presetting 19
Muting the Sound 14

O

Optical Connection 12

P

Playback Operation 14
Power Connection 13
Preset Stations 19
PTY search 20

R

RDS search 20
Rear Panel 6
Remote Control 7

S

Setting the System 23
STEREO 15
Subwoofer Connection 10
Surround Mode 15

T

TP search 20
Tuning 19

Number

3D STEREO 15
3D SURROUND 15

Memo

S9/S7

SOUND PANORAMA
SON PANORAMIQUE
SONIDO PANORAMA
KLANGPANORAMA
ЗВУКОВАЯ ПАНОРАМА



Printed in China
Imprimé en Chine
Impreso en China
Gedruckt in China
Отпечатано в Китае
5707-00000-801-05