SERVICE BULLETIN			15-May2003	Model: DR6000, DR6050, CDR631, CDR500	
			1 / 1	REF.NBR: MZ02-031	
Circulation:	Application:	Subject	::		
x for information customer complaint in case of service mandatory	G. D.I.	Repla MAR	itor on the CDR module of		
	See Below	Int.ref:			

[PHENOMENON]

The chip capacitor is likely to be damaged in the inconsistency of voltage proof. But, a problem symptom doesn't appear.

[SOLUTION]

The chip capacitor is changed to 0.1uF/50V on the CDR Module of MAR770/MAR775.

POS.NO.: 2725

2726 2727

Refer to the following of the service manual.

MAR770/MAR775 CDR Module (service manual part no.: 385K855020)

CDR MAIN BOARD - BOTTOM VIEW: POWER PART TESTPOINTS

CDR 3rd gen. 7. GB70 position B5

[NECESSARY PART]

DK98104300 (0.1uF/50V)

[REMARKS]

This improvement has been done in the production line after

the Lot number MZxxxxxx17xxxx and later.(DR6000)

the Lot number MZxxxxxx13xxxx and later.(DR6050)

the Lot number MZxxxxxx15xxxx and later.(CDR631)

the Lot number MZxxxxxx11xxxx and later.(CDR500)

The Lot number is mentioned the serial number label on the rear panel.

(ex.MZxxxxxx17xxxx)

SERVICE BULLETIN			Date: 10-May-01 Model: DR6000/DR6050/CDR631/C				
			1/2	REF.NB	MZ01-015		
			Subject:				
Circulation:	Application:						
x for information customer complaint in case of service	ALL	Improvement for OPC error and Finalize error,e					
mandatory		Int.ref	•				

[PHENOMENON]

Since a certain CD-R disc made in Taiwan is low quality, OPC is not completed normally.

[SOLUTION]

Please check the version of each software using the service mode.

If the versions are earlier than <DASP: MAR2.15> and <MACE(SPICE): 2.11+>, update each software referring to attachment sheet.

Please refer to the service manual for CDR module MAR770/MAR775. (3120 785 22620, 385K855020) about details of updating software.

Please contact to MARANTZ office about the firmware <DASP> and <MACE(SPICE)>.

[REMARK]

OPU value realignment is mandatory after replace the <MACE(SPICE):2.11+> EPROM.

Please refer to the service manual for CDR module MAR770/MAR775. (3120 785 22620, 385K855020) about details of above alignment.

MZ01-015 Page 2/2

MODULE SOFTWARE		REVERSION	MODIFICATION (Improved symptom)	How to update	Update to latest version DR6000 DR6050 CDR631 CDR500				181201-013 Fage 2/2	
					DR6000	DR6050	CDR631	CDR500	COMMENTS	
DASP		MAR2.5	First version	update by FLASH99	NO	NO	i	ı	Update is necessary when CD software up to V3.6 only.	
		MAR2.8	Track inclement timing delay (200ms) from DAT has improved. Update for professional CDR's.	update by FLASH99	NO	NO	NO	-	Update is necessary when CD software up to V3.6 only.	
	DASP	IIVIAR / 1.3	DAO function has been added. Update for CD V3.6 combination.	update by FLASH99	NO	NO	NO	YES		
CDR	CDR	MAR2.14	Update for other CDR's. (not related with MARANTZ ones)	update by FLASH99	NO	NO	NO	YES		
MAR770 or MAR775 MACE		MAR2.15	Improvement for miss CD-TEXT recording from normal CD while Improvement for miss CD-TEXT recording of "Album Performer" while DAO.	-	NO	NO	NO	NO		
		2.01	First version	EPROM 7208 replacement	YES	YES	i	-	OPU readjustment and Beta alignment by ComPair are	
	MACE	2.02+	Update for professional CDR's.	EPROM 7208 replacement	YES	YES	YES	-	mandatory.	
		2.08+	OPC algorithm improved for 80 min CDR Disc and etc	EPROM 7208 replacement	YES	YES	YES	YES		
		2.11+	OPC algorithm more improved for most CDR Discs.	-	NO	NO	NO	NO		
CD		V3.4	First version	IC 7202 replacement	-	NO	-	-	Update will be appreciated to complained product only.	
MAR1250		V3.6	Improvement for missing start part of tracks after the track search. Improvement for CD playability.	-	-	NO	-		IC7202(S87C654) code number is 3104 123 85630. The CD software V3.6 must be kept combination with DASP MAR2.13 or higher version.	

marantz			22-Nov-01	Model: DR4	050/DR6000/DR605 CDR500/CDR631			
			1/1	REF.NB	MZ01-019			
SERVICE BULLETIN		Subject:						
Circulation:	Application:							
x for information customer complaint in case of service	See below	Improvement for inoperable all buttons						
mandatory 		Int.ref	:					

[PHENOMENON]

While CD is played or CD-R/RW is recorded, the FL display is frozen and all buttons will not be worked. (except POWER button.)

[SOLUTION]

Replace the DASP IC **POS No.7701**> with a new one **(8204 056 03460, QC05603460).**

[REMARK]

<Application LOT number>

DR4050: 01 - 11 LOT DR6000: 01 - 16 LOT DR6050: 01 - 12 LOT CDR500: 01 - 10 LOT CDR631: 01 - 14 LOT

This improvement has been done in the production line after

the LOT number "12" and later. (DR4050)

the LOT number "17" and later. (DR6000)

the LOT number "13" and later. (DR6050)

the LOT number "11" and later. (CDR500)

the LOT number "15" and later. (CDR631)

The lot number and the service modification code are mentioned in the serial number label on the rear panel. (ex. MZxxxxxx12xxxx)