

13,7-45 m

45-160 m


160-585 m

9636, Z = 5 Ω

110 V, 125 V, 145 V,


200 V, 225 V, 245 V

50 watt



13,7-45 m	A	13,7-45 m	B	160-585 m	B
C3, C4, C5 max.		20,5 Mc/s		C3, C4, C5 + 15°	
452 kc/s-33000 pF-g1B2		C3, C4, C5 20,5 Mc/s		1740 kc/s	
S25-30 pF		C15, C8 max.		C26, C17, C10 max.	
S26, S27 max.				-25 pF-aB2	
S24-30 pF				C5	
S25 max.		45-160 m	B	600 kc/s	
S23-30 pF				600 kc/s	
S24 max.		C3, C4, C5 + 15°		C3, C4, C5 600 kc/s	
S23-30 pF		6,1 Mc/s		C5	
S23 max.		C25, C16, C9 max.		C30 max.	
160-585 m	D			C3, C4, C5 + 15°	
857 kc/s				1740 kc/s	
C3, C4, C5				C26, C17, C10 max.	
350 m					

15° - 89 992 44.0





R10360

C1	45 μF	49 032 01.0	R1	1090 Ω	49 356 30.0
C2	45 μF	49 032 01.0	R2	0,82 MΩ	49 375 59.0
C3	11-490 pF		R3	39 Ω	49 375 07.0
C4	11-490 pF	49 000 09.0	R4	10000 Ω	49 377 36.0
C5	11-490 pF		R5	0,15 MΩ	49 375 50.0
C6	10000 pF	49 127 14.0	R6	3,3 MΩ	49 377 66.0
C7	68 pF	49 055 48.0	R7	150 Ω	49 375 14.0
C8	20 pF	49 005 85.2	R8	50000 Ω	49 377 48.0
C9	20 pF	49 005 85.2	R9	220 Ω	49 375 16.0
C10	20 pF	49 005 85.2	R10	33000 Ω	49 375 42.0
C11	100 pF	49 055 28.0	R11	20000 Ω	49 376 36.0
C14	10000 pF	49 128 57.0	R12	5,6 MΩ	49 377 69.0
C15	20 pF	49 005 85.2	R13	47000 Ω	49 375 44.0
C16	20 pF	49 005 85.2	R14	47000 Ω	49 375 44.0
C17	20 pF	49 005 85.2	R15	22000 Ω	49 375 40.0
C19	10000 pF	49 127 14.0	R16	68000 Ω	49 375 46.0
C20	0,1 pF	49 128 53.0	R17	0,65 MΩ	49 500 19.0
C21	100 pF	49 055 28.0	R17a	0,2 MΩ	
C22	150 pF	49 055 30.0	R18	1000 Ω	49 375 24.0
C23	220 pF	49 055 32.0	R19	1 MΩ	49 376 60.0
C24		49 005 13.0	R20	180 Ω	49 376 15.0
C25	20 pF	49 005 85.2	R21	47000 Ω	49 375 44.0
C26	20 pF	49 005 85.2	R22	1,5 MΩ	49 376 42.0
C27	5750 pF	28 195 69.0	R23	82000 Ω	49 375 47.0
C28	1600 pF	49 080 34.0	R24	1800 Ω	49 375 27.0
C29	400 pF	49 057 00.0	R25	0,35 MΩ	49 470 31.0
C30	125 pF	28 212 07.0	R28	5,6 MΩ	49 377 69.0
C31	100 pF		R29	12000 Ω	49 375 37.0
C32	106 pF		R30	12000 Ω	49 375 37.0
C33	47000 pF	49 127 61.0	R31	2700 Ω	49 375 29.0
C34	10000 pF	49 127 57.0	R32	47000 Ω	49 375 44.0
C35	10000 pF	49 128 57.0	R33	39000 Ω	49 375 43.0
C36	100 pF	49 055 28.0	R40	2,2 MΩ	49 377 64.0
C37	106 pF		R41	2,2 MΩ	49 377 64.0
C38	113 pF		R42	1 MΩ	49 376 60.0
C39	100 pF	49 055 28.0	R43	1,5 MΩ	49 376 62.0
C40	27000 pF	49 127 19.0	R44	0,82 MΩ	49 375 59.0
C41	3300 pF	49 128 08.0			
C42	25 pF	49 020 00.0			
C43	330 pF	49 055 05.0			
C44	4700 pF	49 126 54.0			
C47	1000 pF	49 126 53.0			
C51	22000 pF	49 129 98.0			
C52	0,22 pF	49 128 45.0			
C54	2,2 pF	49 055 61.0			
C58	47000 pF	49 127 61.0			
C59	47000 pF	49 127 61.0			

	B1	B2	B3	B4	B5	B7
	EF8	ECH 3B	EBF 2	EL 3	AZ 1	EM4
Va	150	aH 220 aT 115	225	255		20
Vg2	170	B0	85	225		225
Vk	0,3	1,2	0	6,2		0
Ia	7,6	aH 1,4 aT 4,6	4,6	32		0,2 0,1
Ig2	0,2	2,2	1,5	3,1		0,6

S1, S2, S3, S4	A1 653 44.3
S5, S6, S7, S8	A1 638 61.1
S9, S10	A1 635 64.1
S12, S13, S14	A1 636 62.2
S15, S16	A1 635 65.1
S17, S18, S19, S20	A1 635 63.5
S21, S22	A1 635 66.1
S23, S24, C31, C32	A1 635 67.3
S25, S26, S27	
C37, C38	A1 635 68.5
S28, S29, S30, S31	A1 600 29.0
S32	28 220 51.0
S33	A1 000 32.0



P10487

STRICTLY CONFIDENTIAL
FOR PHILIPS SERVICE DEALERS ONLY

COPYRIGHT 1940

PHILIPS

SERVICE DOCUMENTATION

for receiver

494 A

FOR A.C. MAINS FEEDING.

WAVERANGES

Short wave 1: 13.7—45 m (21.9 -- 6.67 Mc)
Short wave 2: 45 —160 m (6.67— 1.87 Mc)
Medium wave: 160 —560 m (1875 —535 Kc).

CONTROL KNOBS

From right to left:

1. Tuning.
2. Waveband switch.

3. Volume control with mains switch.
4. Tone control.

DIMENSIONS.

Width: 53.5 cm }
Height: 31 cm } knobs included.
Depth: 24 cm }

WEIGHT: 11 kg, tubes included.

TRIMMING THE RECEIVER.

Retrimming is necessary:

- When a coil or condenser in the I.F., H.F. or oscillator part has been renewed.
- When the receiver is not sufficient sensitive or selective. It is not necessary to take the receiver out of its cabinet; all trimmers become accessible after removal of the rear panel and the base plate. The positions of the trimmers are indicated in figs. 4 and 5. As regards the necessary trimming tools vide the list of parts and tools. On all wavebands the oscillator frequency is higher than the tuning frequency of the H.F. circuits.
The I.F. is 452 kc.
The I.F. bandwidth 1 : 10 is $11\frac{3}{4}$ kc.
The bandwidth at 1000 kc 1 : 10 is $10\frac{3}{4}$ kc.

A. L.F. CIRCUITS.

1. Earth the set and switch to medium wave band. Turn the variable condenser to minimum position.
2. Connect the output indicator via a trimming transformer to the extension loudspeaker sockets.
3. Apply a modulated signal of 452 kc via a condenser of 32000 pF to the first grid of L2.
4. Detune the third circuit by connecting a condenser of 80 pF in parallel with S25.
5. Tune S26-S27 to maximum output, then remove detuning condenser from S25.
6. Detune the second circuit by connecting a condenser of 80 pF in parallel with S24.
7. Tune S25 to maximum output.
8. Remove the detuning condenser from S24 and detune the first circuit by connecting a condenser of 80 pF in parallel with S23.
9. Tune S24 to maximum output.
10. Remove the detuning condenser and detune the second circuit by connecting a condenser of 80 pF in parallel with S24.
11. Tune S23 to maximum output. Remove detuning condenser and seal the cores.

B. H.F. AND OSCILLATOR CIRCUITS.

1. Earth the set and switch to short wave band 1.
2. Connect the output indicator to the set to be trimmed.
3. Apply to the aerial socket, via the short wave dummy aerial, a modulated signal of 20.5 Mc.
4. Accurately tune the receiver to this frequency by means of the variable condenser (first maximum starting from minimum capacity).

5. Tune C15, C8 to maximum output. Seal trimmers CR, C15.
NOTE. C24 is tuned to a fixed capacity and may not be altered.

II. SHORT WAVE 2 (45—160 m).

1. Fit the 15° gauge.
Switch the set to short wave band 2.
2. Apply a modulated signal of 6.1 Mc via the short wave dummy aerial to the aerial socket.
3. Accurately tune the set to this frequency with the aid of C25, C16 and C9.
4. Seal the trimmers.

III. MEDIUM WAVES (160—560 m).

1. Fit the 15° gauge.
Switch the set to medium waves.
2. Apply a modulated signal of 1740 kc to the aerial socket via the normal dummy aerial.
3. Accurately tune the set to this frequency with the aid of C26, C17 and C10.
4. Connect an auxiliary receiver to the anode of L2 via a condenser of 25 pF, and the output indicator to the auxiliary receiver. Short-circuit C5.
5. Apply to the aerial socket of the set to be trimmed via the normal dummy aerial, a modulated signal of 600 kc.
6. Accurately tune the set to this frequency with the tuning knob.
7. Take away the auxiliary receiver; connect the output indicator to the set to be trimmed. Remove the short-circuit of C5.
DO NOT TURN THE VARIABLE CONDENSER.
8. Tune C30 to maximum output.
9. Turn the variable condenser against the 15° gauge.
10. Apply to the aerial socket of the set to be trimmed, via the normal dummy aerial, a signal of 1740 kc.
11. Tune C26, C17 and C10 to maximum output. Seal C10, C17, C26 and C30.

C. ADJUSTING THE DIAL.

1. Switch the receiver to the medium wave band. Connect the output indicator.
2. Apply to the aerial socket, via a normal dummy aerial, a modulated signal of 857 kc. (350 m).
3. Accurately tune the receiver to this frequency.
4. Slightly loosen the screw on the pointer for attaching the spring and move the pointer until it points exactly to 350 m.
5. Tighten the screw.

REPAIRS AND RENEWAL OF PARTS.

For various kinds of repairs it is not necessary to take the receiver out of the cabinet as often removal of the rear panel and the base plate suffices.

TAKING THE CHASSIS OUT OF THE CABINET.

1. Remove the rear panel.
2. Remove the knobs.
3. Unscrew the connection of the chassis with the bottom-screening.
4. Unsolder the connections to the loudspeaker.
5. Take off the tuning cross.
6. Slightly loosen the screw on the pointer for fixing the string, so that the string is released.
7. Unscrew the chassis from the bottom.
8. Slide the chassis out of the cabinet.
After having returned the chassis into the cabinet, the pointer must be correctly adjusted (vide sheet 1 "Adjusting the dial").

RENEWING THE DIAL.

1. Unscrew the 4 screws A (fig. 8).
The ornamental window can now be removed together with the scale, that can now be renewed easily.

RENEWING THE POINTER.

1. Slightly loosen the screw on the pointer for fixing the string, so that the string is released.
2. Undo the lower guide shaft for the pointer by loosening the two nuts near the end of this shaft.
3. Loosen the pointer from the pointer runner and screw on a new one.

NOTE. The new pointer must be covered at the extremities with silk yarn; the length of the covered part is ± 8 mm.

ADJUSTMENT OF THE LINE OF LIGHT.

If the line of light is not clearly defined, this can be corrected by adjusting the distance of the guide shafts till the scale by means of the nuts at the end of the shafts.

MICROFONIC EFFECT.

To avoid microphony, the variable condenser with the driving mechanism is fixed resiliently to the chassis by means of rubber ducts. This combination must therefore always be set up freely.

The following faults may lead to microphony:

1. Rubber ducts worn out.
2. Connections at the variable condenser too stiff or too taut.
3. The fixing strip 18 (fig. 6) is clamped to tight between the bracket on the variable condenser and the bracket on the chassis. This is to be remedied by unscrewing and fixing again the bracket on the variable condenser.

DRIVING CABLES.

The way the driving cables have to run is indicated in fig. 6. Length of the string for driving the pointer 970 mm. Length of the cord for driving the variable condenser 660 mm. The length of the driving strings is measured from fixing point to fixing point. To allow for the loops, the strings must be cut slightly longer.

LIST OF PARTS AND TOOLS.

When ordering parts, please always mention:

1. Codenumber;
2. Description;
3. Typenumber of the receiver.

Fig.	Pos.	Description	Codenumber	Price
7	1	Cabinet (colour 038)	23 661 35.0	
7	2	Ornamental window (colour 038)	23 690 47.1	
7	3	Stationamedial	A1 896 38.0	
		Stationamedial for British India	A1 896 39.0	
		Stationamedial for South-Africa	A1 896 40.0	
		Stationamedial for the Mediterranean	A1 896 41.0	
7	4	Knob for wavebandswitch (colour 038)	23 613 02.0	
7	5	Knobs, other than pos. 4 (colour 038)	23 612 29.0	
7	6	Wooden panel	A1 931 38.1	
7	7	Loudspeakercloth	06 601 40.0	
7	8	Decorative strip (long one)	A1 343 28.0	
7	9	Decorative strip (short one)	A1 343 27.0	
		Trade mark	28 713 27.1	
		Rear panel	A1 356 84.0	
8	10	Glass pointer	57 027 76.0	
8	11	Screw for fixing the shafts for guiding the pointer	A1 854 62.0	
8	12	Flat spring under the two higher screws of pos. 11	A1 978 92.1	
8	13	Spiral spring under the two lower screws of pos. 11	A1 973 18.0	
6	37	Driving drum	23 687 13.1	
6	32	Spring for the pointerstring	28 740 59.0	
6	31	Spring for the driving cord	28 740 51.0	
6	34	Vernier unit	A1 322 06.0	
6	35	Flat spring for pos. 34	28 751 81.1	
6	36	Fibre strip for pos. 34	28 681 11.1	
6	39	Cogwheel	A1 346 10.0	
6	38	Spring for pos. 39	28 730 85.0	
6	33	Shaft for wavebandswitch	A1 436 68.0	
		Switch element no. 1	49 543 08.1	
		Switch element no. 2	49 543 30.1	
		Switch element no. 3	49 543 44.0	
		Mains voltage connecting plate	28 875 39.0	
		Valveholder for L2 (colour 344)	28 839 81.0	
		Gramophone switch	A1 133 35.0	
		Rubber grommet under the variable condenser	28 725 52.0	
LOUDSPEAKER.				
		Service clamping ring	25 871 81.0	
		Paper ring	28 451 54.0	
		Cone with coil	28 220 51.1	
TOOLS.				
		Service oscillator	GM 2880F	
		Universal Measuring Apparatus	GM 4256	
		Universal and Valve Measuring Apparatus	GM 7629	
		15°-gauge	09 992 44.0	
		Centring-gauge for loudspeaker	09 991 53.0	
		Insulated trimming screw driver	M646 38.2	
		Insulated trimming key 6 mm	23 685 66.0	

COILS.

	Value	Codenumber	Price		Value	Codenumber	Price
S1				S21	2 Ohm	A1 035 66.1	
S2	200 Ohm			S22	5.5 Ohm		
S3	^ 1 Ohm	A1 055 44.3		S23	7 Ohm	A1 035 67.1	
S4	^ 1 Ohm						
S5	^ 3 Ohm			S24	7 Ohm		
S6	^ 1 Ohm	A1 035 61.1		C31	100 pF	A1 035 68.2	
S7	^ 7 Ohm						
S8	0.8 Ohm			S25	10 Ohm		
S9	20 Ohm	A1 035 64.0		S26			
S10	4 Ohm						
S12	^ 1 Ohm	A1 035 62.2		S27	6 Ohm		
S13	^ 1 Ohm						
S14	^ 1 Ohm			C37	106 pF	A1 103 29.0	
S15	^ 3 Ohm	A1 035 65.1		C38	113 pF		
S16	^ 1 Ohm				S28	600 Ohm	
S17	^ 1 Ohm			S29	< 1 Ohm		
S18	^ 1 Ohm	A1 035 63.5		S30	230 Ohm		
S19	^ 1 Ohm						
S20	^ 1 Ohm			S31	230 Ohm		
				S32	4 Ohm	28 220 51.1	
				S35	700 Ohm	A1 000 32.0	

RESISTANCES.

	Value	Codenumbr	Price
R1	1800 Ohm	49 356	30.0
R2	0.82 M.Ohm	49 375	59.0
R3	39 Ohm	49 375	07.0
R4	10000 Ohm	49 377	36.0
R5	0.15 M.Ohm	49 375	50.0
R6	3.3 Ohm	49 377	66.0
R7	150 Ohm	49 375	14.0
R8	0.1 M.Ohm/2 =		
	50,000 Ohm	49 377	48.0
R9	220 Ohm	49 375	16.0
R10	33000 Ohm	49 375	42.0
R11	2 × 10,000 Ohm =		
	20,000 Ohm	49 376	36.0
R12	5.6 M.Ohm	49 377	69.0
R13	47000 Ohm	49 375	44.0
R14	47000 Ohm	49 375	44.0
R15	22000 Ohm	49 375	40.0
R16	68000 Ohm	49 375	46.0
R17	0.65 M.Ohm		
R17a	0.2 M.Ohm	49 500	19.0
R18	1000 Ohm	49 375	24.0
R19	1 M.Ohm	49 376	60.0
R20	180 Ohm	49 376	15.0
R21	47000 Ohm	49 375	44.0
R22	1.5 M.Ohm	49 376	62.0
R23	82000 Ohm	49 375	47.0
R24	1800 Ohm	49 375	27.0
R25	0.35 M.Ohm	49 470	31.0
R28	5.6 M.Ohm	49 377	69.0
R29	12000 Ohm	49 375	37.0
R30	12000 Ohm	49 375	37.0
R31	2700 Ohm	49 375	29.0
R32	47000 Ohm	49 375	44.0
R33	39000 Ohm	49 375	43.0
R40	2.2 M.Ohm	49 377	64.0
R41	2.2 M.Ohm	49 377	64.0
R42	1 M.Ohm	49 376	60.0
R43	1.5 M.Ohm	49 376	62.0
R44	0.82 M.Ohm	49 375	59.0

TUBES.

L1	L2	L3	L4	L5	L6	L7
EF8	ECH3 B	EBF2	EL3	AZ1	8091 D-00	EM4

CURRENTS AND TENSIONS.

	Va	Va tr.	Vg2	Vkath	Ia	Ia tr.	Ig2
L1	150		170	0.3	7.6		0.2
L2	220	115	80	1.2	1.4	4.6	2.2
L3	225		85	0	4.6		1.5
L4	255		225	6.2	32		3.1
L7	20		225	0	0.2 and 0.1		0.6

Ve1 = 275 V. Ve2 = 225 V.
Primary consumption = 50 Watt.

CONDENSERS.

	Value	Codenumbr	Price
C1	48 μF	49 025	22.0
C2	48 μF	49 025	22.0
C3	11-490 pF		
C4	11-490 pF	49 000	09.0
C5	11-490 pF		
C6	10000 pF	49 127	14.0
C7	68 pF	49 055	48.0
C8	20 pF	49 005	03.0
C9	20 pF	49 005	03.0
C10	20 pF	49 005	03.0
C11	100 pF	49 055	49.0
C14	10000 pF	49 128	57.0
C15	20 pF	49 005	03.0
C16	20 pF	49 005	03.0
C17	20 pF	49 005	03.0
C19	10000 pF	49 127	14.0
C20	0.1 μF	49 128	63.0
C21	100 pF	49 055	28.0
C22	150 pF	49 055	30.0
C23	220 pF	49 055	32.0
C24		49 005	13.0
C25	20 pF	49 005	05.0
C26	20 pF	49 005	03.0
C27	5750 pF	28 195	69.0
C28	1600 pF	49 080	34.0
C29	400 pF	49 057	00.0
C30	125 pF	28 212	07.0
C31	100 pF		
C32	106 pF		Vide "Coils"
C33	47000 pF	49 127	61.0
C34	10000 pF	49 127	57.0
C35	10000 pF	49 128	57.0
C36	100 pF	49 055	28.0
C37	106 pF		
C38	113 pF		Vide "Coils"
C39	100 pF	49 055	28.0
C40	27000 pF	49 127	15.0
C41	3300 pF	49 128	08.0
C42	25 μF	49 020	00.0
C43	330 pF	49 055	05.0
C44	4700 pF	49 126	54.0
C47	1000 pF	49 126	53.0
C51	22000 pF	49 129	90.0
C52	0.22 μF	49 128	65.0
C54	2 × 2.2 pF par.	49 055	61.0
C58	47000 pF	49 127	61.0
C59	47000 pF	49 127	61.0

S:	12.34	37.9	6.810	12.15	14.15	16.16	17.18	21	18.20	25.24	25.26	27	35.28	30.31	32																																
C:	7	51	6.18	8.10	3.27	23.59	14.58	13.16	17.4	18	20.21	22.5	90.87	28.29	34.21	25.26	31.32	33.34	52	55.89	37.40	38.41	36	44.42	43.44	47																					
R:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47





Fig 1

494A




5767

S:	3, 2, 1	4	34.
C:		81.	
R:		24	11.
		43, 51.	

Fig 2

R 591

494A



R 992

Fig 3

494A

S	35	30, 32, 31, 29	34	21, 22, 25, 22, 24, 15	20, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100	2, 14, 15, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100
C	47, 43	44	36, 2	38, 39, 35, 34, 33, 32, 31, 30, 29, 28, 27, 26, 25, 24, 23, 22, 21, 20, 19, 18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1	5, 4, 3, 2, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100	2, 14, 15, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100
R	25	43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100	30	41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100	2, 14, 15, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100	2, 14, 15, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100




Fig 4

R993

494 A




Fig 5

R404




Fig 6

494A

