


KDC-5080R/RY, KDC-6016R SERVICE MANUAL

KENWOOD

© 2000-2 PRINTED IN JAPAN
B51-7593-00 (N) 2209

Extension cord	Parts No.
CD mechanism(22P)	W05-0618-00



The MECHANISM OPERATION DESCRIPTION is the same as model KDC-S3007 and KDC-5050RG.

Please refer to the service manual for model KDC-S3007(B51-7029-00) or KDC-5050RG(B51-7099-00).




KDC-5080R/RY,6016R

CONTENTS

BLOCK DIAGRAM	3
COMPONENTS DESCRIPTION	4
MICROCOMPUTER'S TERMINAL DESCRIPTION	6
TEST MODE	8
ATTENTION	9
PC BORD	10
SCHEMATIC DIAGRAM	17
EXPLODED VIEW	25
PARTS LIST	27
SPECIFICATIONS	34

KDC-5080R/RY,6016R

BLOCK DIAGRAM



KDC-5080R/RY,6016R

COMPONENTS DESCRIPTION

●MAIN UNIT

Ref.No.	Component Name	Application/Function	Operation/Condition/Compatibility
IC1	784217AGF505	System MI-COM.	
IC2	S-80830ANNP	Reset IC	"Lo": Detection voltage below 3.0V
IC3	HD74HC27FP	Mute logic	3 input NOR gate x3
IC150	TDA7479D	RDS decoder	
IC300	TDA7400D	E-VOL. & N.C. MPX	
IC500	TDA7386	Power IC	
Q1	2SA1576A	SW 5V	ON when the base goes "Lo".
Q2	DTA124EUA	Mute driver for Audio mute SW	ON when the base goes "Lo".
Q3	DTA144EUA	Changer reset SW	ON when the base goes "Lo".
Q5	2SA1576A	Panel 5V SW	ON when the base goes "Lo" during the panel not detached.
Q100	2SA1703-AN	FM+B SW	Q100 is turned ON when Q101's base goes "Hi".
Q101	DTC144EUA		ON during FM reception.
Q102	2SA1703-AN	AM+B SW	Q102 is turned ON when Q103's base goes "Hi".
Q103	DTC144EUA		ON during AM reception.
Q104	2SC4081	Composite out buffer	
Q300	DTA124EUA	Noise detection time constant SW	OFF during FM seek, ON during FM reception.
Q301	DTC114TUA		Q301 is turned On when Q300's emitter goes "Hi".
Q302	2SC4081	Noise buffer	
Q303	DTC144EUA	E-VOL. mute SW	E-VOL. is muted when the base goes "Hi".
Q350A,B	DTC343TK	Audio mute SW	Audio pre-outs are muted when the base goes "Hi".
Q351A,B	DTC343TK	Audio mute SW	Audio pre-outs are muted when the base goes "Hi".
Q500	DTC114YUA	SVR SW	POWER IC RESET is activated when the base goes "Hi".
Q600	2SC4081	BU detection(Momentary power down detection)	ON when the base goes "Hi" during BU applied.
Q601	2SC4081	ACC detection	ON when the base goes "Hi" during ACC applied.
Q604	2SA1703-AN	P CON SW	Q604 is turned ON when Q607's base goes "Hi".
Q607	DTC114EUA		ON during POWER ON mode except ALL OFF mode.
Q605	2SA1576A	P CON protection	Protect Q604 by turning ON when P-CON output is grounded.
Q606	DTA124EUA		Prevents Q605 tuning ON during start-up after power ON.
Q610	2SB1565(E,F)	BU 5V AVR	Inverted darlington connection.
Q611	2SC4081		ON during BU applied.
Q612	2SD1760	Illumination AVR	ON when the base goes "Hi".
Q614	DTA124EUA	Illumination AVR SW	Q614 is turned ON when Q615's base goes "Hi".
Q615	DTC124EUA		
Q618	2SB1565(E,F)	Servo AVR	Inverted darlington connection.
Q620	2SC4081		Q618 is turned ON when Q620's base goes "Hi".
Q621	DTA124EUA	SW 14V	Audio 8V AVR and Servo AVR ON/OFF control.
Q624	DTC144EUA		Q621 is turned ON when Q624's base goes "Hi".
Q622	2SB1565(E,F)	Audio 8V AVR	Inverted darlington connection.
Q625	2SC4081		Q622 is turned ON when Q625's base goes "Hi".

KDC-5080R/RY,6016R

COMPONENTS DESCRIPTION

● CONTROL UNIT

Ref.No.	Component Name	Application/Function	Operation/Condition/Compatibility
IC900	LC75883E	LCD driver with key-matrix	
IC901	RS-171	Remote control IC	
Q900	DTA124EUA	Remote SW	ON when the base goes "Lo".
Q901	2SD2114K	Key illumination green SW	ON when the base goes "Hi".
Q902	2SD2114K	Key illumination red SW	ON when the base goes "Hi".
Q903	DTA124EUA	Key-matrix permission SW	ON when the base goes "Lo".

● CD PLAYER UNIT(X32-4700-00)

Ref.No.	Component Name	Application/Function	Operation/Condition/Compatibility
IC1	AN8806SB	RF amplifier	Generation of RF signal based on the signals from the APC circuit and pickup, and generation of servo error(focusing error and tracking error)signals. Detection of dropout, anti-shock, track crossing and off-track conditions.
IC2	MN662774KC3	CD signal processor built-in MI-COM.	Focusing, tracking, sled and spindle servo processing. Automatic adjustment(focusing, tracking, gain, offset and balance)operations. Digital signal processing(DSP, PLL, sub-codes, CIRC error correction, audio data interpolation)operations.
IC4	BA5917AFF	BTL driver	Focusing coil, tracking coil, spindle motor and sled motor driver.
IC5	TA78L05F	5V AVR	
IC6	NJM4565MD	Low pass filter	
Q1	2SB1188	APC	LD power control.
Q2	DTC124EUA	P ON SW	ON during the CD source selected.
Q3	2SA1362(Y)	A.8V SW	A8V line ON/OFF control.
Q4	2SA1362(Y)	D.5V SW	D5V line ON/OFF control.
Q5	DTC124EUA	MOTOR ON SW	ON during CD loading or eject action .
Q8	DTC124EUA	GAIN CONTROL SW	

KDC-5080R/RY,6016R

MICROCOMPUTER'S TERMINAL DESCRIPTION

●Terminal description

PinNo.	Pin name	I/O	Description	Processing Operation
1	ST TYPE1	I	IC2 setting terminal	"Lo": Initial value
2	ST TYPE2	I	IC2 setting terminal	"Lo": Initial value
3	JS TYPE1	I	Genuine/After market distinction terminal	"Hi": Genuine, "Lo": After market
4	TYPE1	I	Destination type input terminal 1	
5	TYPE2	I	Destination type input terminal 2	
6	TYPE3	I	Destination type input terminal 3	
7	NC	O	Not used	
8	NC	O	Not used	
9	VDD	-	Power supply connection terminal	Connected to BU 5V lines.
10	NC	O	Not used	
11	NC	O	Not used	
12	NC	O	Not used	
13	RDS DATA	I	Data input from the RDS decoder IC	
14	RDS QUAL	I	Quality input from the RDS decoder IC	
15	AFC	O	AFC control output	"Hi": During FM reception, "Lo": During FM seek.
16	FM/AM SD	I	SD input from the tuner pack	"Hi": Station detected, "Lo": Not detected
17	IF COUNT	I	Not used	
18	NC	O	Not used	
19	REMO	I	Data input from the remote control light sensor	
20	AM+B	O	AM+B control	"Hi": During AM reception.
21	FM+B	O	FM+B control	"Hi": During FM reception.
22	TEST	-	IC test terminal(Not used)	Connected to GND
23	IC2 SDA	I/O	Data input/output with the E-VOL. IC	
24	IC2 SCK	O	Clock output to the E-VOL. IC	
25	MUTE	O	Mute control output	"Hi": Mute ON, "Lo": Mute OFF
26	SW5V	O	SW 5V control output	"Lo": POWER ON mode or during CD loading or eject action.
27	F/E DATA	I/O	Data input/output with the front end	
28	F/E CLK	O	Clock output to the front end	
29	CH CON	O	Changer control	"Hi": ON, "Lo": Standby
30	CH REQH	O	Request output to changers	"Lo": Request
31	CD MUTE	I	Muting request from the MI-COM. of CD mecha.	"Lo": Mute request
32	CD MRST	O	Reset output to the MI-COM. of CD mecha.	"Lo": Reset
33	CD MSTOP	O	Stop request to the MI-COM. of CD mecha.	"Lo": Stop
34	CD LO/EJ	I/O	CD mecha. loading/Eject switching output	"Lo": Loading, "Hi": Eject, "Hi-Z": Stop
35	CD LMON	O	CD mechanism loading motor control output	"Hi": CD loading or eject action, "Lo": other
36	CD SW3	I	Down & limit switch detection input	"Hi": Chucking, "Lo": Pickup most inner position
37	VDD	-	Power supply connection terminal	Connected to BU 5V lines.
38	X2	-	Main clock resonator connection terminal	
39	X1	-	Main clock resonator connection terminal	
40	VSS	-	Ground connection terminal	Connected to GND.
41	XT2	-	Sub clock resonator connection terminal	
42	XT1	-	Sub clock resonator connection terminal	
43	RESET	I	Reset input terminal	"Lo": System reset
44	NC	O	Not used	
45	RDS CLK	I	Clock input from the RDS decoder IC	
46	CH REQC	I	Request input from changers	"Lo": Request
47	LCD DATAL	I	Data input from the LCD driver IC	
48	CD SW2	I	12cm disc detection terminal	When 12cm disc was detected, the input becomes "Lo" temporarily.
49	CD SW1	I	Loading detection	"Lo": CD chucking.
50	NC	O	Not used	

KDC-5080R/RY,6016R

MICROCOMPUTER'S TERMINAL DESCRIPTION

PinNo.	Pin name	I/O	Description	Processing Operation
51	AVDD	-	A/D converter power supply connection terminal	Connected to BU 5V lines.
52	AVREF0	-	A/D converter reference voltage input terminal	Connected to BU 5V lines.
53	PHONE	I	PHONE detection input	1V or less: TEL MUTE, 2.5V or greater: NAVI MUTE
54	NC	I	Not used	Pull down to GND.
55	NOISE	I	Noise detection input	
56	S-METER	I	S-meter input from the front end	
57	NC	I	Not used	Pull down to GND.
58	NC	I	Not used	Pull down to GND.
59	NC	I	Not used	Pull down to GND.
60	NC	I	Not used	Pull down to GND.
61	AVSS	-	A/D, D/A converter ground connection terminal	Connected to GND.
62	NC	O	Not used	
63	NC	O	Not used	
64	AVREF1	-	D/A converter reference voltage input terminal	
65	CH DATA C	I	Data input from changers	
66	CH-DATA H	O	Data output to changers	
67	CH CLK	I/O	Clock input/output with changers	
68	LCD DATA L	I	Data input from the LCD driver IC	
69	LCD DATA S	O	Data output to the LCD driver IC	
70	LCD CLK	O	Clock output to the LCD driver IC	
71	NC	O	Not used	
72	BEEP	O	BEEP sound output	
73	NC	O	Not used	
74	PNL DET1	I	Panel detaching detection input	"Hi": Panel detached.
75	NC	O	Not used	
76	LCD INH	O	INH output to the LCD driver IC	"Lo": LCD indication OFF.
77	LCD CE	O	CE output to the LCD driver IC	"Hi": Active
78	SRT SW1	I	SRT position detection input	Panel : (SW1, SW2)=(Hi, Hi) Slide : (SW1, SW2)=(Hi, Lo) Mask : (SW1, SW2)=(Lo, Lo)
79	SRT SW2	I	SRT position detection input	
80	NC	O	Not used	
81	NC	O	Not used	
82	NC	O	Not used	
83	NC	O	Not used	
84	NC	O	Not used	
85	NC	O	Not used	
86	NC	O	Not used	
87	AMP SVR	O	Power IC reset output	When the momentary power down, after ACC OFF is detected and after POWER OFF, the output goes "Hi" temporarily.
88	AMP STBY	O	Power IC standby control output	"Hi": POWER ON mode
89	AMP MUTE	O	Power IC mute control output	"Lo": Mute
90	NC	O	Not used	
91	ILL ON	O	Illumination AVR ON/OFF control output	"Hi": AVR ON
92	P ON	O	Microprocessor peripheral power supply control output	"Hi": ACC ON or during CD loading or eject action.
93	SMALL	I	Small lights detection input	"Lo": During vehicle small lamps turn on.
94	P ANT	O	Antenna control output	"Hi": During FM/AM reception.
95	P CONT	O	Power control output	"Hi": POWER ON mode except ALL OFF mode.
96	ACC DET	I	ACC detection input	"Hi": ACC OFF, "Lo": ACC ON
97	BU DET	I	Momentary power down detection input	"Hi": When momentary power down detected or BU OFF, "Lo": BU ON
98	AMP CONT	O	External amp. control output	
99	NC	O	Not used	
100	VSS	-	Ground connection terminal	Connected to GND.

KDC-5080R/RY,6016R

TEST MODE

•TEST MODE SPECIFICATIONS

(1) How to enter the test mode

While holding the FM and Preset 6 keys simultaneously, reset the unit.

All indicators and display segments are ON at the start of test mode.

(2) How to exit from the test mode

Reset the unit.

(Note) The test mode cannot be canceled by turning Acc OFF, power OFF or momentary power down.

(3) Test mode specifications of the CD receiver

Each press of the Track Up key jumps to the following tracks.

No. 9⇒No. 15⇒No. 10⇒No. 11⇒No. 12⇒No. 13⇒

No. 14⇒No. 9 (return to beginning)

Pressing the Track Down key jumps to the previous track to the track being played.

(4) Audio

•The volume is -10 dB (displayed as 30).

•LOUD is OFF, and CRSC is also OFF whether the function is provided or not.

•With the Bass/Treble and Balance/Fader controls, pressing the Up/Down key switch the setting alternately to:

Full Boost ⇒ Full Cut ⇒ Full Boost, Full Right⇒
Full Left ⇒ Full Right, or Full Front ⇒ Full Rear ⇒
Full Front.

•With the high-pass filter, pressing the Up key sets it to Through/100 Hz/200 Hz and pressing the Down key sets it to 200 Hz/100 Hz/Through.

•Other adjustments function in the same way as normal mode.

(5) Backup current measurement

When the unit is reset (backup turned on) while Acc is OFF or when Acc is turned OFF in test mode, the MUTE terminal goes on in 2 seconds, instead of 1.5 second.

(The panel, CD, C and MD mechanisms are not activated at this time.)

(6) Security code registration after E2PROM replacement servicing (E/M type only)

1. Enter the test mode. (See (1) How to enter the test mode.)

2. Press the SRC key to set All OFF.

3. Press and hold the AUDIO key for 1 second to enter menu mode.

4. Press the FM/AM key to select "SECURITY".

5. Press and hold the Track Up/Down for 2 seconds.

6. Enter the code by pressing the Preset 1, 2, 3 and 4 keys.

Example: To enter "3510",

•Press the Preset 1 key 4 times.

•Press the Preset 2 key 6 times.

•Press the Preset 3 key 2 times.

•Press the Preset 4 key once.

7. Press and hold the DISPLAY key for 3 seconds to display "APPROVED".

8. Quit the test mode (See (2) How to exit from the test mode.)

(7) How to clear the simple security code (K type only)

1. While the code is requested, press and hold the DISP key and press and hold the VOL Up key for 3 seconds.

("----" disappears.)

2. Enter "KCAR" from the remote control unit. (Same operation as the '98 model)

•Press numeric key 5 twice then press the Track Up key. (This enters "K".)

•Press numeric key 2 three times then press the Track Up key. (This enters "A".)

•Press numeric key 2 once then press the Track Up key. (This enters "A".)

•Press numeric key 7 twice then press the Track Up key. (This enters "R".)

3. The security is canceled and the unit enters the TUNER mode.

(8) Other

•The DNPP/SBF key of the remote control unit (RC-510) functions as the menu mode ON/OFF key.

•The OPEN/CLOSE key of the remote control unit (RC-510) functions as the audio adjustment mode ON/OFF key.

•The menu is displayed by displaying only the required features.

•Message such as "CODE OFF" is not displayed when power is turned ON.

•The contrast can be adjusted only to 0/5/10 using the Up/Down keys.

KDC-5080R/RY,6016R


ATTENTION

Assembly of FPC(Flexible PC board) onto Roller ass'y

Turn Roller ass'y by 4 times.


Hook the end of Roller ass'y to the tongue.

Insert the FPC into the slit of Roller ass'y then release the end of Roller ass'y and the tongue.




PC BOARD (COMPONENT SIDE VIEW)

CONTROL UNIT



PC BOARD (FOIL SIDE VIEW)

CONTROL UNIT




IC	O	address
900		4B
901	900	3B
	901	3B
	902	6B
	902	6A
	903	6B

IC	O	address
900		4D
901	900	3D
	901	3D
	902	6D
	902	6E
	903	6D


10 Refer to the schematic diagram for the values of resistors and capacitors.

PC BOARD (COMPONENT SIDE VIEW)

MAIN UNIT




SWITCH UNIT




IC	Q	address
1		5K
2		5J
3		5I
300		4H
500		5N
1		5J
2		5I
3		6J
5		6K
100		3G
101		3G
102		2H
103		3G
303		4I
350A		3J
350B		3I
351A		3I
351B		3I
352A		3I
352B		3I
353A		3I
353B		3I
354A		3I
354B		3I
501A		2H
501B		3G
502A		3K
502B		3K
503A		3K
503B		3K
504A		3K
504B		3K
505A		3K
505B		3K
506A		3K
506B		3K
507		3K
508		3K
509		3K
510		3K
511		3K
512		3K
600		4K
601		3K
602		3K
603		3K
604		3K
605		3K
606		3K
607		3K
608		3K
609		3K
610		3K
611		3K
612		3K
613		3K
614		3K
615		3K
616		3K
617		3K
618		3K
619		3K
620		3K
621		5H
622		5H
623		5H
624		5H
625		5H

PC BOARD (FOIL SIDE VIEW)




IC	Q	address
1		5T
2		5T
3		5V
300		4V
500	1	5Q
	2	5T
	3	5V
	5	6U
	100	6T
	101	2W
	102	3W
	103	2W
	303	3W
	350A	4V
	350B	3U
	351A	3V
	351B	5R
	600	4S
	601	3S
	602	3T
	603	3T
	604	3T
	605	3T
	606	3T
	607	3T
	610	6W
	611	6W
	612	6R
	614	6Q
	615	6Q
	618	6W
	620	6W
	621	5W
	622	5W
	624	5W
	625	5W




Z AA AB AC AD AE AF AG AH AI

1

PC BOARD (COMPONENT SIDE VIEW)




(FOIL SIDE VIEW)





IC	1	2	4	5	6
address	5AA	5AB	2AC	3AC	4AC
Q	1	2	3	4	5
address	5Z	5AC	3AC	4AB	5AC


IC	1	2	4	5	6
address	5AH	5AG	2AF	3AF	4AF
Q	1	2	3	4	5
address	5AI	5AF	3AF	4AG	5AF



2SB1565

DTA144EUA
DTC114YUA
DTC343TK
2SA1362
2SA1576A
2SD2114K

2SB1188




2SD1760

2SC4081


2SC4081

DTA124EUA
DTC114EUA
DTC124EUA
DTC144EUA


NJM4565MD




DAN202U




TA78L05F




DA204K




AN8806SB




TDA7479D





CAUTION : For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list).
 △ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.
 • DC voltages are as measured with a high impedance voltmeter. Values may vary slightly due to variations between individual instruments or/and units.

KDC-5080R/RY,6016R
KENWOOD




CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list).

△ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

• DC voltages are measured with a high impedance voltmeter. Values may vary slightly due to variations between individual instruments or/and units.

KDC-5080R/RY,6016R

KENWOOD



CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list).

△ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.


* DC voltages are as measured with a high impedance voltmeter. Values may vary slightly due to variations between individual instruments or/and units.

KDC-5080R/RY,6016R

KENWOOD

KDC-5080R/RY,6016R


EXPLODED VIEW (MECHANISM)



Parts with the exploded numbers larger than 700 are not supplied.

KDC-5080R/RY,6016R

EXPLODED VIEW (UNIT)



KDC-5080R/RY,6016R

PARTS LIST

*New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description	Desti nati on	Ref. No.	A d d	N e w	Parts No.	Description	Desti nati on
KDC-5080R/RY,6016R											
200	1C	*	A02-1494-08	PLASTIC CABINET ASSY		251	2C	*	H12-2671-08	CUSHION (BRACKET MIDDLE)	
202	1D	*	A52-0769-08	TOP PLATE		252	2C	*	H13-1782-08	FPC PROTECT COVER	
205	2C	*	A11-0995-08	PANEL BRACKET ASSY		253	1D	*	H21-1127-08	PROTECTION SHEET (CD&FPC)	
206	2C	*	A11-0996-08	SIDE PLATE L ASSY		-	-	*	H10-4714-08	POLYSTYRENE FORMED FIXTURE	M2
207	2C	*	A11-0997-08	SIDE PLATE R ASSY		-	-	*	H10-4723-08	POLYSTYRENE FORMED FIXTURE (J)	
208	2C	*	A22-2846-08	SUB PANEL ASSY		-	-	*	H25-0329-04	PROTECTION BAG	
209	2C	*	A46-1674-08	REAR COVER		-	-	*	H25-0334-04	PROTECTION BAG	
PA1	3C	*	A64-2092-08	PANEL ASSY		-	-	*	H25-0336-04	PROTECTION BAG	
RC1	1C		A70-0883-05	REMOTO CONTROLLER ASSY(RC-500)	M2	-	-	*	H54-1724-08	ITEM CARTON CASE	M2
-	-	-	-	-		-	-	*	H54-1725-08	ITEM CARTON CASE	E4
212	1D	*	B07-2186-08	ESCUCHONEON(J-CAR)	M2	-	-	*	H54-1732-08	ITEM CARTON CASE	E5
213	3D	*	B07-2195-08	ESCUCHONEON ASSY		255	2C	*	J19-5023-08	DUMPER	
214	3C	*	B10-3214-08	FRONT GLASS ASSY	M2	257	1C	*	J21-9585-08	Mounting hardware assy	
214	3C	*	B10-3215-08	FRONT GLASS ASSY	E4E5	258	2C	*	J31-1048-08	COLLER	
215	3C	*	B19-2041-08	HOLDER		259	2C	*	J39-0841-08	PROTECTION SHEET (BRACKET ARM)	
-	-	-	B46-0100-50	WARRANTY CARD	M2E4	260	2C	*	J52-0604-05	PUSH LATCH	
-	-	-	B46-0612-14	ID CARD		261	1C		J54-0611-08	STAY	M2
-	-	-	B58-1319-04	CAUTION CARD	E4E5	264	3C	*	K24-3591-08	KNOB (SRC)	
-	-	*	B59-0742-00	SUB INSTRUCTION MANUAL	E4E5	265	3C	*	K24-3592-08	KNOB (OPEN)	
-	-	*	B64-1626-00	INST.MANUAL(ENG,CHI)	M2	266	3C	*	K24-3630-08	KNOB (RELEASE)	
-	-	*	B64-1627-00	INST.MANUAL(ENGLISH)	E4E5	267	3C	*	K25-1152-08	KNOB (VOL)	
-	-	*	B64-1628-00	INST.MANUAL(FRE,GER,DUT)	E4	268	3C	*	K25-1153-08	KNOB (PLAY/PAUSE,EJECT)	
-	-	*	B64-1629-00	INST.MANUAL(ITA,SPA,POR)	E4	269	3C	*	K25-1154-08	KNOB (PRESET,ATT)	
-	-	*	B64-1630-00	INST.MANUAL(RUS,POL,CZE)	E5	270	3C	*	K25-1155-08	KNOB (AUD,AUTO,DISP)	
-	-	*	B64-1631-00	INST.MANUAL(HUN,SWE,FIN)	E5	271	3C	*	K25-1156-08	KNOB (FM,AM,UP,DOWN)	
218	2D	*	D10-4500-08	ARM (RELEASE)		274	1C	*	N99-1688-08	SCREW SET	
219	2C	*	D10-4501-08	LEVER (SW)		275	1C	*	N99-1689-08	SCREW SET	M2
220	3C	*	D10-4502-08	LEVER (LOCK)		A	3D	*	N09-4387-08	SCREW	
221	2C	*	D10-4503-08	GEAR (ARM)		B	3C	*	N09-4388-08	SCREW	
222	1D	*	D10-4514-08	LEVER		C	2C	*	N19-2148-08	C WASHER	
223	2C	*	D13-2088-08	GEAR (IDOL)		D	2C	*	N19-2149-08	C WASHER	
224	2C	*	D14-0745-08	ROLLER (FPC)		E	2C	*	N29-0518-08	E RING	
225	2D	*	D21-2351-08	SHAFT (RELEASE H)		F	2C	*	N35-2003-45	SCREW	
228	3C	*	E29-1807-08	CONDUCTIVE RUBBER		G	2C	*	N35-2004-45	SCREW	
230	1D	*	E30-4857-08	ANT CORD ASSY		H	3C	*	N35-2605-46	SCREW	
231	2D	*	E30-4859-08	RCA CORD ASSY		J	2C	*	N35-3004-45	SCREW	
232	2C	*	E39-0360-08	FPC ASSY		K	2C	*	N09-4392-08	SCREW	
233	2C		E58-0895-05	RECTANGULAR RECEPTACLE (13P)		L	2C	*	N39-2025-46	SCREW	
DC1	1C	*	E30-4868-08	DC CORD	M2	M	3C	*	N80-2008-45	SCREW	
DC2	1C	*	E30-4869-08	DC CORD	E4E5	N	1D	*	N83-3006-46	SCREW	
FC1	1C	*	E39-0359-08	FLAT CABLE (22P)		P	3D	*	N84-3008-46	SCREW	
235	2C	*	F07-1089-08	COVER (MASK)		Q	2D	*	N86-3005-46	SCREW	
236	2C	*	F09-1637-08	ADHESIVE SHEET(MASK)		276	1C		T90-0523-05	ANT ADAPTER E4E5	E4E5
238	1D		F29-0049-05	INSULATING COVER (RCA PIN)		DME1	1D		X92-3690-01	CD MECHANISM ASSY	
F1	1C		F06-1032-05	FUSE(BLADE TYPE)(10A)							
241	2C	*	G01-3030-08	TORSION COIL SPRING (SW LEVER)							
242	2D	*	G01-3031-08	TORSION COIL SPRING (RELEASE)							
243	2C	*	G01-3032-08	TORSION COIL SPRING (FPC)							
244	2C	*	G01-3033-08	TORSION COIL SPRING (BRACKET)							
245	3C	*	G01-3034-08	COMPRESSION SPRING (OPEN)							
246	3C	*	G01-3035-08	EXTENSION SPRING (LOCK LEVER)							
249	2C	*	G13-1248-08	CUSHION (BRACKET LEFT)							
250	2C	*	G16-1154-08	PROTECTION SHEET(BRACKET ASSY)							
MAIN UNIT											
C1			CE04CW1A101M	ELECTRO	100UF	10WV					
C2			CK73GB1H103K	CHIP C	0.010UF	K					
C3	,		CC73FC1H220J	CHIP C	22PF	J					
C6			CK73EB1C105K	CHIP C	1.0UF	K					
C7			CK73GB1H102K	CHIP C	1000PF	K					
C8	-10		CK73GB1H103K	CHIP C	0.010UF	K					

KDC-5080R/RY,6016R

PARTS LIST

*New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

MAIN UNIT

Ref. No.	A d	N ew	Parts No.	Description	Dest inati on	Ref. No.	A d	N ew	Parts No.	Description	Dest inati on
C13-17			CK73GB1H103K	CHIP C 0.010UF K		C609			CK73FB1H103K	CHIP C 0.010UF K	
C18,19			CK73GB1H102K	CHIP C 1000PF K		C610,611			CE04CW1C101M	ELECTRO 100UF 16WV	
C100			CK73GB1H103K	CHIP C 0.010UF K		C612		*	C90-5327-08	CHIP-TAN 10UF 16WV	
C101			CE04CW1A101M	ELECTRO 100UF 10WV		C613			CK73GB1H223K	CHIP C 0.022UF K	
C102			CK73GB1H103K	CHIP C 0.010UF K		C614			CE04CW1A101M	ELECTRO 100UF 10WV	
C103			CE04CW1A101M	ELECTRO 100UF 10WV		C615			CK73GB1H223K	CHIP C 0.022UF K	
C104			CK73GB1C104K	CHIP C 0.10UF K		C618			CK73GB1H223K	CHIP C 0.022UF K	
C105			CK73GB1H103K	CHIP C 0.010UF K		C619			CE04CW1C470M	ELECTRO 47UF 16WV	
C106			CE04CW1A101M	ELECTRO 100UF 10WV		C621			CK73GB1H103K	CHIP C 0.010UF K	
C107			CK73GB1H103K	CHIP C 0.010UF K		C622			CE04CW1C470M	ELECTRO 47UF 16WV	
C108			CE04CW1A101M	ELECTRO 100UF 10WV		C623			CE04CW1A101M	ELECTRO 100UF 10WV	
C109			CK73GB1C104K	CHIP C 0.10UF K		CN1		*	E41-0068-08	PIN ASSY (4P)	
C110			CE04CW1A101M	ELECTRO 100UF 10WV		CN3			E40-9402-05	FLAT CABLE CONNECTOR (13P)	
C111			CK73GB1H103K	CHIP C 0.010UF K		CN100			E40-3238-05	PIN ASSY (3P)	
C150			C90-2597-05	ELECTRO 10UF 16WV		CN200			E40-9339-05	FLAT CABLE CONNECTOR (22P)	
C151			CC73FCH1H271J	CHIP C 270PF J		CN350			E40-3241-05	PIN ASSY (6P)	
C152			C90-2597-05	ELECTRO 10UF 16WV		CN400	2D		E56-0834-05	CYLINDRICAL RECEPTACLE (13P)	
C153			CK73GB1H103K	CHIP C 0.010UF K		CN600	2D		E58-0863-15	RECTANGULAR RECEPTACLE (16P)	
C154,155			CC73FCH1H100D	CHIP C 10PF D		L1					
C200	*		C90-5325-08	CHIP C 0.047UF K		L100			L33-1055-08	SMALL FIXED INDUCTOR(4.7UH,K)	
C300			CK73EB1C225K	CHIP C 2.2UF K		L101			L33-1055-08	SMALL FIXED INDUCTOR(4.7UH,K)	
C301A,B			CK73EB1C225K	CHIP C 2.2UF K		L102-106			L33-1123-05	LINE FILTER COIL (52mH)	
C302	*		C90-5326-08	CHIP C 0.033UF K		L150			L33-1055-08	SMALL FIXED INDUCTOR(4.7UH,K)	
C303			CK73GB1H153K	CHIP C 0.015UF K		L300			L33-1055-08	SMALL FIXED INDUCTOR(4.7UH,K)	
C304			CK73FB1C474K	CHIP C 0.47UF K		X1		*	L78-0815-08	SMALL FIXED INDUCTOR(4.7UH,K)	
C305			CC73FCH1H151J	CHIP C 150PF J		X2			L78-0533-05	SERAMIC RESONATOR (12.0MHZ)	
C306			CK73GB1C104K	CHIP C 0.10UF K		X150			L77-2002-05	RESONATOR (32.768KHZ)	
C307			CC73FCH1H121J	CHIP C 120PF J		P	3D		N84-3008-46	SCREW	
C308			CK73GB1C823K	CHIP C 0.082UF K		R	3D		N30-3008-46	SCREW	
C309			CE04CW1C470M	ELECTRO 47UF 16WV		S	2D		N83-3008-45	SCREW	
C310			CK73GB1H103K	CHIP C 0.010UF K		JC1			R92-2053-05	CHIP R 0 J 1/8W	
C350A,B			ELECTRO 10UF 16WV			JC2			R92-2052-05	CHIP R 0 J 1/10W	
C351A,B			C90-2597-05	ELECTRO 10UF 16WV		JC3,4			R92-2053-05	CHIP R 0 J 1/8W	
C352A,B			CK73GB1H222K	CHIP C 2200PF K		JC5-7			R92-2052-05	CHIP R 0 J 1/10W	
C353A,B			CK73GB1H222K	CHIP C 2200PF K		JC8-10			R92-2053-05	CHIP R 0 J 1/8W	
C354			CK73FB1E104K	CHIP C 0.10UF K		JC11-13			R92-2052-05	CHIP R 0 J 1/10W	
C400			CK73FB1E104K	CHIP C 0.10UF K		JC14			R92-2053-05	CHIP R 0 J 1/8W	
C402A,B			C90-2606-05	ELECTRO 0.47UF 50WV		JC15,16			R92-2052-05	CHIP R 0 J 1/10W	
C403			CE04CW1C470M	ELECTRO 47UF 16WV		JC17			R92-2053-05	CHIP R 0 J 1/8W	
C404A,B			CK73GB1H102K	CHIP C 1000PF K		JC18,19			R92-2052-05	CHIP R 0 J 1/10W	
C502A,B			CK73FB1C474K	CHIP C 0.47UF K		R1			RK73GB1J473J	CHIP R 47K J 1/16W	
C503A,B			CK73FB1C474K	CHIP C 0.47UF K		R3			RK73GB1J473J	CHIP R 47K J 1/16W	
C504A,B			CK73FB1C474K	CHIP C 0.47UF K		R5			RK73GB1J473J	CHIP R 47K J 1/16W	
C505A,B			CK73FB1C474K	CHIP C 0.47UF K		R7			RK73GB1J473J	CHIP R 47K J 1/16W	
C506,507			CK73EB1C225K	CHIP C 2.2UF K		R8			RK73GB1J473J	CHIP R 47K J 1/16W	M2
C508,509			C90-2877-08	ELECTRO 1.0UF 50WV		R10,11			RK73GB1J473J	CHIP R 47K J 1/16W	E4E5
C511			CE04CW1C101M	ELECTRO 100UF 16WV		R13			RK73FB2A102J	CHIP R 1.0K J 1/10W	
C600	*		C90-5328-08	ELECTRO 3900UF 16WV		R14			RK73EB2B225J	CHIP R 2.2M J 1/8W	
C601			CK73EB1H104K	CHIP C 0.10UF K		R15-17			RK73FB2A103J	CHIP R 10K J 1/10W	
C602			CK73FB1E104K	CHIP C 0.10UF K		R18			RK73FB2A102J	CHIP R 1.0K J 1/10W	
C603			CK73FB1H103K	CHIP C 0.010UF K		R19			RK73FB2A472J	CHIP R 4.7K J 1/10W	
C604			CK73FB1E104K	CHIP C 0.10UF K		R20			RK73FB2A473J	CHIP R 47K J 1/10W	
C605			CE04CW1H3R3M	ELECTRO 3.3UF 50WV		R21,22			RK73FB2A103J	CHIP R 10K J 1/10W	
C606			CK73FB1E683K	CHIP C 0.068UF K							
C607			CE04CW1H0R1M	ELECTRO 0.1UF 50WV							

PARTS LIST

*New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

MAIN UNIT

Ref. No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref. No.	A d d	N e w	Parts No.	Description	Dest inati on
R23			RK73FB2A473J	CHIP R	47K J 1/10W	R401A,B			RK73FB2A101J	CHIP R	100 J 1/10W
R24			RK73FB2A104J	CHIP R	100K J 1/10W	R402			RK73FB2A101J	CHIP R	100 J 1/10W
R25			RK73FB2A222J	CHIP R	2.2K J 1/10W	R403-405			RK73FB2A222J	CHIP R	2.2K J 1/10W
R27			RK73FB2A222J	CHIP R	2.2K J 1/10W	R406,407			RK73FB2A472J	CHIP R	4.7K J 1/10W
R32			RK73FB2A104J	CHIP R	100K J 1/10W	R408			RK73FB2A101J	CHIP R	100 J 1/10W
R33			RK73FB2A470J	CHIP R	47 J 1/10W	R409			RK73FB2A104J	CHIP R	100K J 1/10W
R34			RK73FB2A221J	CHIP R	220 J 1/10W	R500A,B			RK73FB2A472J	CHIP R	4.7K J 1/10W
R35			RK73FB2A102J	CHIP R	1.0K J 1/10W	R501A,B			RK73FB2A472J	CHIP R	4.7K J 1/10W
R36			RK73FB2A154J	CHIP R	150K J 1/10W	R502			RK73FB2A333J	CHIP R	33K J 1/10W
R39 ,40			RK73FB2A102J	CHIP R	1.0K J 1/10W	R503			RK73FB2A223J	CHIP R	22K J 1/10W
R43			RK73FB2A473J	CHIP R	47K J 1/10W	R504			RK73FB2A751J	CHIP R	750 J 1/10W
R44			RK73FB2A471J	CHIP R	470 J 1/10W	R505			RK73FB2A431J	CHIP R	430 J 1/10W
R45			RK73FB2A473J	CHIP R	47K J 1/10W	R506			RK73FB2A102J	CHIP R	1.0K J 1/10W
R46			RK73FB2A471J	CHIP R	470 J 1/10W	R508			RK73FB2A273J	CHIP R	27K J 1/10W
R47			RK73FB2A473J	CHIP R	47K J 1/10W	R509			RK73FB2A101J	CHIP R	100 J 1/10W
R50			RK73FB2A101J	CHIP R	100 J 1/10W	R600			RK73FB2A183J	CHIP R	18K J 1/10W
R51 ,52			RK73FB2A102J	CHIP R	1.0K J 1/10W	R601			RK73FB2A822J	CHIP R	8.2K J 1/10W
R53			RK73FB2A221J	CHIP R	220 J 1/10W	R602			RK73FB2A223J	CHIP R	22K J 1/10W
R54 ,55			RK73FB2A471J	CHIP R	470 J 1/10W	R603			RK73FB2A104J	CHIP R	100K J 1/10W
R56			RK73FB2A470J	CHIP R	47 J 1/10W	R604			RD14DB2H332J	SMALL-RD	3.3K J 1/2W
R57			RK73FB2A221J	CHIP R	220 J 1/10W	R605			RK73EB2B473J	CHIP R	47K J 1/8W
R58			RK73FB2A104J	CHIP R	100K J 1/10W	R606			RK73FB2A912J	CHIP R	9.1K J 1/10W
R59			RK73FB2A473J	CHIP R	47K J 1/10W	R607			RK73FB2A104J	CHIP R	100K J 1/10W
R60			RK73FB2A273J	CHIP R	27K J 1/10W	R608			RK73FB2A472J	CHIP R	4.7K J 1/10W
R61 ,62			RK73FB2A473J	CHIP R	47K J 1/10W	R611			RK73FB2A472J	CHIP R	4.7K J 1/10W
R64			RK73FB2A684J	CHIP R	680K J 1/10W	R612			RD14DB2H102J	SMALL-RD	1.0K J 1/2W
R65			RK73FB2A223J	CHIP R	22K J 1/10W	R613			RK73FB2A223J	CHIP R	22K J 1/10W
R67 ,68			RK73FB2A471J	CHIP R	470 J 1/10W	R614			RD14DB2H102J	SMALL-RD	1.0K J 1/2W
R69			RK73FB2A102J	CHIP R	1.0K J 1/10W	R617			RK73FB2A473J	CHIP R	47K J 1/10W
R100			RK73EB2B151J	CHIP R	150 J 1/8W	R618			RK73EB2B752J	CHIP R	7.5K J 1/8W
R101			RK73FB2A223J	CHIP R	22K J 1/10W	R619			RK73FB2A223J	CHIP R	22K J 1/10W
R102			RK73EB2B222J	CHIP R	2.2K J 1/8W	R620			RK73FB2A102J	CHIP R	1.0K J 1/10W
R103			RK73FB2A223J	CHIP R	22K J 1/10W	R621			RK73FB2A104J	CHIP R	100K J 1/10W
R104			RK73EB2B222J	CHIP R	2.2K J 1/8W	R622,623			RK73FB2A102J	CHIP R	1.0K J 1/10W
R105			RK73FB2A102J	CHIP R	1.0K J 1/10W	R624			RK73FB2A223J	CHIP R	22K J 1/10W
R106			RK73FB2A472J	CHIP R	4.7K J 1/10W	R625			RD14BB2E100J	RD	10 J 1/4W
R200			RK73FB2A104J	CHIP R	100K J 1/10W	R626			RK73FB2A102J	CHIP R	1.0K J 1/10W
R201			RK73FB2A222J	CHIP R	2.2K J 1/10W	R627			RK73FB2A471J	CHIP R	470 J 1/10W
R300			RK73FB2A103J	CHIP R	10K J 1/10W	R634			RK73FB2A152J	CHIP R	1.5K J 1/10W
R301			RK73FB2A272J	CHIP R	2.7K J 1/10W	R641			RK73FB2A102J	CHIP R	1.0K J 1/10W
R302,303			RK73FB2A472J	CHIP R	4.7K J 1/10W	R643			RK73FB2A103J	CHIP R	10K J 1/10W
R305			RK73FB2A222J	CHIP R	2.2K J 1/10W	R644			R92-2052-05	CHIP R	0 J 1/10W
R306			RK73FB2A102J	CHIP R	1.0K J 1/10W	RN1			R90-0724-05	MULTI-COMP	1K X4
R307			RK73FB2A472J	CHIP R	4.7K J 1/10W	RN2 -4			R90-0725-05	MULTI-COMP	1K X2
R308			RK73FB2A102J	CHIP R	1.0K J 1/10W	RN5			R90-0724-05	MULTI-COMP	1K X4
R309A,B			R92-2052-05	CHIP R	0 J 1/10W	RN6			R90-0725-05	MULTI-COMP	1K X2
R310A,B			R92-2052-05	CHIP R	0 J 1/10W	RN7			R90-1022-05	MULTI-COMP	470 X2
R311A,B			R92-2052-05	CHIP R	0 J 1/10W	RN9			R90-0720-05	MULTI-COMP	100K X4
R352A,B			RK73FB2A471J	CHIP R	470 J 1/10W	RN150			R90-0722-05	MULTI-COMP	2.2K X4
R353A,B			RK73FB2A471J	CHIP R	470 J 1/10W	RN400			R90-0720-05	MULTI-COMP	100K X4
R354A,B			RK73FB2A223J	CHIP R	22K J 1/10W	D5 -8			MA4062(N)-M	ZENER DIODE	
R355A,B			RK73FB2A223J	CHIP R	22K J 1/10W	D100			MA4051(N)-M	ZENER DIODE	
R356A,B			RK73FB2A101J	CHIP R	100 J 1/10W	D300			1SS355	DIODE	
R357A,B			RK73FB2A101J	CHIP R	100 J 1/10W	D301			RD6.8MW	ZENER DIODE	
R400			RK73FB2A101J	CHIP R	100 J 1/10W	D350A,B			STZ6.2Z	ZENER DIODE	

KDC-5080R/RY,6016R

PARTS LIST

*New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

MAIN UNIT

Ref. No.	A d	N e w	Parts No.	Description	Dest inati on	Ref. No.	A d	N e w	Parts No.	Description	Dest inati on
D352A,B			STZ6.2Z	ZENER DIODE		Q620			2SC4081	TRANSISTOR	
D400A,B			STZ6.2Z	ZENER DIODE		Q621			DTA124EUA	DIGITAL TRANSISTOR	
D401-405			STZ6.2Z	ZENER DIODE		Q622	2D		2SB1565(E,F)	TANSISTOR	
D501			1SS355	DIODE		Q624			DTC144EUA	DIGITAL TRANSISTOR	
D502A,B			11ES2C	DIODE		Q625			2SC4081	TRANSISTOR	
D503A,B			11ES2C	DIODE		TH500		*	TH470	THERMISTOR	
D504A,B			11ES2C	DIODE		TU100	2D		X86-3162-70	FRONT-END UNIT	
D505A,B			11ES2C	DIODE							
D506,507			1SS355	DIODE							
D600			RM10Z	ZENER DIODE							
D601			HZS6B1L	ZENER DIODE							
D603			HZS6B1L	ZENER DIODE							
D604,605			11ES2C	DIODE	E45						
D606			11ES2C	DIODE	M2						
D607			11ES2C	DIODE							
D608			1SS355	DIODE							
D610			MA4047-M	ZENER DIODE							
D612			11ES2C	DIODE							
D613			HZS6B1L	ZENER DIODE							
D614			MA4110-L	ZENER DIODE							
D615			MA4082(N)-L	ZENER DIODE							
D617		*	DTZ9.1A	ZENER DIODE							
IC1		*	784217AGF505	MI-COM IC							
IC2		*	S-80830ANNP	ANALOGUE IC							
IC3		*	HD74HC27FP	MOS-IC							
IC150			TDA7479D	ANALOGUE IC							
IC300			TDA7400D	ANALOGUE IC							
IC500			TDA7386	ANALOGUE IC							
Q1			2SA1576A	TRANSISTOR							
Q2			DTA124EUA	DIGITAL TRANSISTOR							
Q3			DTA144EUA	DIGITAL TRANSISTOR							
Q5			2SA1576A	TRANSISTOR							
Q100			2SA1703-AN	TRANSISTOR							
Q101			DTC144EUA	DIGITAL TRANSISTOR							
Q102			2SA1703-AN	TRANSISTOR							
Q103			DTC144EUA	DIGITAL TRANSISTOR							
Q104			2SC4081	TRANSISTOR							
Q300			DTA124EUA	DIGITAL TRANSISTOR							
Q301			DTC114TUA	DIGITAL TRANSISTOR							
Q302			2SC4081	TRANSISTOR							
Q303			DTC144EUA	DIGITAL TRANSISTOR							
Q350A,B			DTC343TK	DIGITAL TRANSISTOR							
Q351A,B			DTC343TK	DIGITAL TRANSISTOR							
Q500			DTC114YUA	DIGITAL TRANSISTOR							
Q600,601			2SC4081	TRANSISTOR							
Q604			2SA1703-AN	TRANSISTOR							
Q605			2SA1576A	TRANSISTOR							
Q606			DTA124EUA	DIGITAL TRANSISTOR							
Q607			DTC114EUA	DIGITAL TRANSISTOR							
Q610	2D		2SB1565(E,F)	TANSISTOR							
Q611			2SC4081	TRANSISTOR							
Q612			2SD1760	TRANSISTOR							
Q614			DTA124EUA	DIGITAL TRANSISTOR							
Q615			DTC124EUA	DIGITAL TRANSISTOR							
Q618	2D		2SB1565(E,F)	TANSISTOR							
CD PLAYER UNIT (X32-4700-00)											
C1 ,2				CK73FB1A105K		CHIP C			1.0UF	K	
C3				C92-1359-05		CHIP-TAN			10UF	16WV	
C4				C92-0566-05		CHIP-TAN			10UF	6.3WV	
C5				CC73FCH1H330J		CHIP C			33PF	J	
C6				CC73FCH1H030C		CHIP C			3.0PF	C	
C7				CK73FB1C104K		CHIP C			0.10UF	K	
C8				CK73FB1A105K		CHIP C			1.0UF	K	
C9				CC73FCH1H101J		CHIP C			100PF	J	

E4: KDC-5080R E5: KDC-5080RY M2: KDC-6016R

KDC-5080R/RY,6016R

PARTS LIST

*New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

CD PLAYER UNIT (X32-4700-00)

Ref. No.	A d d	N e w	Parts No.	Description	Dest inati on
IC6			NJM4565MD	IC(OP AMP X2)	
Q1			2SB1188	TRANSISTOR	
Q2			DTC124EUA	DIGITAL TRANSISTOR	
Q3 ,4			2SA1362(Y)	TRANSISTOR	
Q5			DTC124EUA	DIGITAL TRANSISTOR	
Q8			DTC124EUA	DIGITAL TRANSISTOR	
CD MECHANISM ASSY (X92-3690-01)					
1	2A	A10-4482-01	CHASSIS		
2	1B	A10-4225-33	CHASSIS CALKING ASSY		
3	2B	A11-0915-43	SUB CHASSIS CALKING ASSY		
5	2A	D10-3082-13	ARM		
6	2A	D10-4306-04	ARM ASSY		
7	2A	D10-4305-04	ARM ASSY		
8	3A	D10-3087-44	ARM ASSY		
9	3B	D10-3092-03	SLIDER		
10	3B	D10-3093-04	SLIDER ASSY		
11	2B	D10-3095-04	SLIDER ASSY		
12	2B	D10-3096-04	SLIDER ASSY		
13	1A	D10-3099-24	SLIDER ASSY		
14	1A	D10-3100-04	SLIDER ASSY		
16	1B	D10-4004-04	LEVER ASSY		
17	1B	D10-4006-04	LEVER		
18	1A	D10-4007-04	LEVER		
19	2B	D10-4008-14	LEVER		
20	2A	D10-4009-23	ARM		
21	3A	D10-4010-04	LEVER		
22	3A	D10-4011-34	LEVER ASSY		
23	3A	D10-4013-14	ARM ASSY		
24	3B	D10-4050-04	ARM		
25	3A	D10-4038-23	ARM ASSY		
26	2A	D10-4123-24	LEVER ASSY		
27	3A	D13-1340-13	RACK (GEAR)		
29	3B	D13-1231-04	GEAR		
30	3A	D13-1240-04	GEAR		
31	3B	D13-1233-04	GEAR		
32	3B	D13-1234-14	GEAR ASSY		
33	3A	D13-1238-03	GEAR		
34	3B	D13-1232-04	GEAR		
35	3B	D13-1241-04	GEAR		
36	3A	D13-1242-04	GEAR		
37	1B	D13-1243-04	GEAR		
38	1B	D13-1244-04	GEAR		
39	1B	D13-1245-14	GEAR		
40	2A	D13-1246-04	GEAR		
41	2B	D13-1247-04	GEAR		
43	2B	D13-1249-04	GEAR ASSY		
44	2B	D13-1341-04	GEAR ASSY (LEAD SCREW)		
45	1B	D14-0668-04	ROLLER		
46	2A	D14-0670-04	ROLLER		
47	3B	D14-0674-04	ROLLER		
49	3A	D21-2228-14	SHAFT		
50	1A	D21-2229-04	SHAFT		
51	1A	D23-0925-24	RETAINER		
52	2A	D32-0614-04	STOPPER		

Ref. No.	A d d	N e w	Parts No.	Description	Dest inati on
53	1B	D39-0223-05	DAMPER (YELLOW)		
54	2B	D39-0224-05	DAMPER (BLACK)		
55	3B	F09-1246-04	SHEET		
58	3B	F09-1266-14	SHEET		
60	2A	G01-2770-04	EXTENSION SPRING		
61	3A	G01-2771-04	EXTENSION SPRING		
62	3A	G01-2772-24	EXTENSION SPRING		
63	3A	G01-2773-14	EXTENSION SPRING		
64	3A	G01-2774-34	EXTENSION SPRING		
65	1B	G01-2775-04	TORSION COIL SPRING		
66	1B	G01-2776-14	TORSION COIL SPRING		
67	3B	G01-2777-24	TORSION COIL SPRING		
69	2A	G01-2844-04	EXTENSION SPRING		
70	2A	G02-1231-04	FLAT SPRING		
71	2B	G02-1232-24	FLAT SPRING		
72	2A	G02-1241-24	FLAT SPRING		
73	2A	G02-1248-14	FLAT SPRING		
75	2A	J11-0613-13	CLAMPER		
76	3A	J19-4678-13	HOLDER		
77	2B	J19-4679-24	HOLDER		
78	3B	J21-7684-13	Mounting Hardware		
79	2B	J21-7686-13	Mounting Hardware		
80	1B	J21-7690-03	Mounting Hardware		
81	3A	J31-1032-04	COLLAR		
82	3A	J84-0107-05	FLEXIBLE PRINTED WIRING BOARD		
83	1A	J90-0757-22	GUIDE		
A	2A	N09-4249-05	MACHINE SCREW (M1.7X2.5,LOCK)		
	1B	N09-4172-05	TAPPING SCREW (2X3.5,CTITE)		
	2B	N09-4202-05	STEPPED SCREW		
	2A	N38-2020-46	PAN HEAD MACHIN SCREW		
	3A	N09-4294-05	TAPITTE SCREW (BIND P TAPIT)		
F	3B	N19-2023-04	FLAT WASHER		
	2A	N19-2058-04	FLAT WASHER		
	3A	N19-2093-04	FLAT WASHER		
	2A	N39-2020-46	PAN HEAD MACHIN SCREW		
DM1	3B	T42-0764-04	DC MOTOR ASSY		
	3B	T42-0763-04	DC MOTOR ASSY		
	2B	T25-0215-05	OPTICAL PICKUP HEAD		

KDC-5080R/RY,6016R

SPECIFICATIONS

	Model	KDC-5080R/RY	KDC-6016R
FM	Frequency Range (Frequency step)	87.5MHz~108.0MHz(50kHz)	87.5MHz~108.0MHz(50kHz)
	Channel Space Selection	-	50kHz
	Usable Sensitivity (S/N 26dB)	0.7μ V/75Ω	-
	Usable Sensitivity (S/N 30dB)	-	9.3dBf (0.8μ V/75Ω)
	Quieting Sensitivity (S/N 46dB)	1.6μ V/75Ω	-
	Quieting Sensitivity (S/N 50dB)	-	15.2dBf (1.6μ V/75Ω)
	Frequency Response (±3.0dB)	30Hz~15kHz	30Hz~15kHz
	S/N	65dB(MONO)	70dB(MONO)
	Selectivity(DIN)	≥80dB(±400kHz)	-
	Selectivity	-	≥80dB(±400kHz)
	Stereo Separation	35dB(1kHz)	40dB(1kHz)
MW	Frequency Range (Frequency step)	531kHz~1611kHz(9kHz)	531kHz~1611kHz(9kHz)
	Usable Sensitivity (S/N 20dB)	25μ V	25μ V
LW	Frequency Range	153kHz~281kHz	153kHz~281kHz
	Usable Sensitivity (S/N 20dB)	45μ V	45μ V
CD	Laser Diode	GaAlAs(λ=780nm)	GaAlAs(λ=780nm)
	Digital Filter(D/A)	8 Times Over Sampling	8 Times Over Sampling
	D/A Converter	1 Bit	1 Bit
	Spindle Speed	500~200rpm(CLV)	500~200rpm(CLV)
	Wow & Flutter	Below Measurable Limit	Below Measurable Limit
	Frequency Response	10Hz~20kHz(±1dB)	10Hz~20kHz(±1dB)
	THD	0.01%(1kHz)	0.01%(1kHz)
	S/N Ratio	93dB(1kHz)	93dB(1kHz)
	Dynamic Range	93dB	93dB
	Channel Separation	85dB	85dB
Preout Level/Load		1800mV/10kΩ(CD/CD-CH)	1800mV/10kΩ(CD/CD-CH)
Preout Impedance		≤600Ω	≤600Ω
AMPLIFIER	Maximum Power	45Wx4	45Wx4
	Power DIN45324,+B=14.4V	28Wx4	-
	Full Bandwidth Power (at less than 1% THD)	-	22Wx4
TONE	Bass	100Hz±10dB	100Hz±10dB
	Treble	10kHz±10dB	10kHz±10dB
GENERAL	Operating Voltage (11V~16V allowable)	14.4V	14.4V
	Current Consumption	10A	10A
	Installation Size(W) (H) (D)	182mm 53mm 161mm	182mm 53mm 161mm
	Weight	1.8kg	1.8kg

KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo 150-8501 Japan

KENWOOD SERVICE CORPORATION

PO. BOX 22745, 2201 East Dominguez Street, Long Beach, CA90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A.

PO. BOX 55-2791, Piso 6, Plaza Chase, Cl. 47 y, Aquilino de la Guardia, Panama,
Republic of Panama

KENWOOD ELECTRONICS BRASIL LTDA.

Av. Moema, 170-17^o, Andar-Cobertura "B", Ed. Maximum Service Center, 04077-020
Moema, São Paulo-SP-Brasil

KENWOOD ELECTRONICS UK LIMITED

Kenwood House, Dwight Road, Watford, Herts, WD1 8EB, United Kingdom

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrücke-Str. 15, 63150 Heusenstamm, Germany

KENWOOD ELECTRONICS FRANCE S.A.

13, Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS BELGIUM N.V.

Mechelsesteenweg 418, B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS ITALIA S.p.A.

Via G. Sirton 7/9, 20129 Milano, Italy

KENWOOD IBÉRICA S.A.

Bolivia, 239-08020 Barcelona, Spain

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD. (A.C.N. 001 499 074)

16 Giffnock Avenue, North Ryde, N.S.W. 2113, Australia

KENWOOD ELECTRONICS (HONG KONG) LTD.

Unit 3712-3724, Level 37, Tower 1, Metroplaza, 223 Hing Fong Road, Kwai Fong, N.T.,
Hong Kong

KENWOOD ELECTRONICS GULF FZE

P.O. Box 61318, Jebel Ali, Dubai, U.A.E.

KENWOOD ELECTRONICS (THAILAND) CO., LTD.

2019 New Pechburi Road, Bangkapi, Huaykwang, Bangkok, 10320 Thailand

KENWOOD ELECTRONICS SINGAPORE PTE. LTD.

1 Genting Lane, #07-00, Kenwood Building, Singapore, 349544

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD

#4.01 Level 4, Wisma Academy Lot 4A, Jalan 19/1, 46300 Petaling Jaya, Selangor Darul Ehsan,
Malaysia